

Installation and Operating Manual



CONTENTS

1	IMPORTANT information about this manual	4
1.1	Scope	4
1.2	Supported products	4
1.3	Documentation contents.	4
1.4	Meaning of symbols	4
1.5	General safety information	5
1.6	Disclaimer	5
1.7	Appropriate use	5
1.8	Guarantee	6
1.9	Requirements for installers	6
2	Safety	7
2.1	Safety information	7
2.2	Data security	8
3	Preparation	9
3.1	Required tools and resources	9
3.2	Preparatory work	9
3.3	Preparation for installation	9
4	Technical Data	10
5	TESVOLT Energy Manager	11
5.1	Scope of delivery	11
5.2	Connections and setup of the TESVOLT Energy Manager	12
5.3	TESVOLT Energy Manager user interface	15
6	Installing the unit	16
6.1	Network structure	16
6.2	Maximum cable lengths for TESVOLT Energy Manager inputs and outputs	19
6.3	Top hat mounting rail installation	19
6.4	Connection of KC4S and DIO-Modul.	19
6.5	24 V power supply	20
6.6	Network	20
6.7	RS-485	20
6.8	Digital Outputs	21
6.9	Connection of the Energy Manager	21
7	Unit setup.	22
7.1	Switch on the TESVOLT Energy Manager	22
7.2	Scanning the network environment.	23
7.3	Setting up a user for the first time	23

7.4	Installation wizard (initial setup)	25
7.5	Firmware Update	26
7.6	Network configuration	26
7.7	RS485 Bus Konfiguration (Modbus-RTU)	28
7.8	User management	29
8	Topology setup	33
8.1	Setting up logical devices	33
8.2	Setting the topology	56
9	Setting up strategies and energy services	64
9.1	Procedure	64
9.2	Overview of energy services.	64
9.3	Actuators and actuator groups	65
9.4	Applications	70
10	System monitoring in myTESWORLD	. 118
10.1	myTESWORLD user interface	. 118
10.2	User management	. 120
10.3	EMS configuration	. 123
10.4	Technician role	. 133
10.5	Customer view	. 137
11	Decommissioning	. 150
12	Firmware-Update	. 150
13	Analysis function and troubleshooting	. 151
13.1	Network analysis	. 151
13.2	Inputs and outputs analysis	. 151
14	Example energy service strategies (multi-use)	. 152
14.1	Peak shaving + self-consumption optimisation	. 152
14.2	Forecast-based charging + self-consumption optimisation	. 153
15	Maintenance	. 155
16	Disposal	. 155
17	Legal notice	. 155

1 IMPORTANT INFORMATION ABOUT THIS MANUAL

1.1 SCOPE


This document applies to the TESVOLT Energy Manager energy management system from version 3.0.3 or higher.

Read this manual thoroughly to ensure error-free installation, initial commissioning and maintenance of the TESVOLT Energy Manager. Installation, initial commissioning and maintenance must be carried out by qualified and authorised specialists. The Installation and Operating Manual should be kept close to the unit and must be accessible at all times to all individuals involved in installation or maintenance.


This Installation and Operating Manual applies to Germany only, without restriction. Ensure that you adhere to the applicable local legal regulations and standards. The standards and legal regulations in other countries may contradict the specifications in this manual. In this case, please contact the TESVOLT Service Line +49 (0) 3491 87 97 - 200.

1.2 SUPPORTED PRODUCTS

The TESVOLT Energy Manager can be used with the TS-IHV 80 battery storage system. Other compatible devices and systems can be found in our technical document "TESVOLT Energy Manager – Compatible Systems and Devices".







1.3 DOCUMENTATION CONTENTS

- TESVOLT Energy Manager installation and operating manual (this document)
- "TESVOLT Energy Manager Compatible Systems and Devices" technical document

1.4 MEANING OF SYMBOLS

Symbols in the manual

This manual contains the following types of warnings and information:



DANGER! Warning notice indicating that death or serious injury may result if you fail to follow the instruction.



CAUTION! Warning notice indicating that injury may result if you fail to follow the instruction.



WARNING! Warning notice indicating that material damage may result if you fail to follow the instruction.



NOTE: This symbol indicates information relating to the use of the unit.

Symbols on the unit

The following types of warnings and information are used on the unit:



The CE marking indicates that the TESVOLT Energy Manager meets the requirements established by the European Union for attaching this marking.



The UKCA marking indicates that the TESVOLT Energy Manager meets the requirements established by the United Kingdom for attaching this marking.



Old electrical and electronic devices frequently contain valuable materials. Old devices should not therefore be disposed of in general waste. Take this unit to a municipal collection point for electronic waste.

1.5 GENERAL SAFETY INFORMATION



DANGER! Failure to observe the safety information can result in danger to life

Improper use can lead to life-threatening injuries. Any person tasked with working on the system must have read and understood this manual, particularly the section "2 Safety" on page 7. All safety information must be followed without fail.

Everyone who works on the TESVOLT Energy Manager must follow the specifications in this manual.

This manual cannot describe every conceivable situation. For this reason, the applicable standards and corresponding occupational health and safety regulations always take priority.

In addition, installation may also involve residual hazards under the following circumstances:

- Installation, commissioning and configuration has not been carried out properly.
- Installation, commissioning and configuration has been carried out by personnel who have not received the relevant training or instruction.
- The warnings and safety information in this manual have not been followed.

1.6 DISCLAIMER

TESVOLT GmbH assumes no liability for personal injury, damage to property, damage to the product and follow-on damage attributable to the following causes:

- Non-compliance with this manual,
- Improper use of the product,
- Repairs, opening the cabinet and other actions performed on or with the product by unauthorised and/or unqualified personnel,
- Use of non-approved spare parts.

Unauthorised modifications or technical changes to the product are forbidden.

1.7 APPROPRIATE USE

TESVOLT Energy Manager is an energy management system comprising a control unit including the relevant measuring equipment and corresponding software. The components were built in accordance with the current state of the art in technology and product-specific standards.

TESVOLT Energy Manager is designed for used with compatible battery storage systems and inverters. Any other use must be agreed with the manufacturer.

The TESVOLT Energy Manager is used for energy management in a commercial enterprise. The unit may only be operated in enclosed spaces. The working ambient temperature range for the

TESVOLT Energy Manager is 0 °C to 50 °C and the maximum relative humidity is 5 to 95 % (non-condensing).

The unit must not be exposed to direct sunlight or placed directly beside sources of heat.

The TESVOLT Energy Manager hardware must not be exposed to corrosive environments.

The hardware and software must not be tampered with.

Adherence to the specifications in this Installation and Operating Manual also forms part of appropriate use.

1.8 GUARANTEE

The current guarantee conditions can be downloaded from the internet by visiting www.tesvolt.com.

1.9 REQUIREMENTS FOR INSTALLERS

The locally applicable regulations and standards are to be adhered to for all work.

The TESVOLT Energy Manager may be installed only by qualified electricians with the following qualifications:

- Training in dealing with hazards and risks encountered when installing and operating electrical equipment and systems,
- · Training in installing and commissioning electrical equipment,
- Knowledge of and compliance with the technical connection conditions, standards, guidelines, regulations and laws applicable on site,
- Knowledge of and adherence to this document and the associated product documentation, including all safety instructions,
- Successful participation in the TESVOLT Energy Manager certification training (information about training courses can be found at www.tesvolt.com; alternatively, please email academy@tesvolt. com).

2 SAFETY

2.1 SAFFTY INFORMATION



DANGER! Life-threatening voltage results in danger to life and health due to electric shock.

- All work on the electrical devices may only be completed by qualified electricians.
- Do not operate the units when damp.
- Do not take the power supply components out of a cold environment into a warm environment immediately before commissioning.



CAUTION! Danger from working on open current transformer circuits. If current transformers are used in the system, care must be taken to ensure that the secondary circuit of the current transformer is short-circuited before working on the current transformer circuits. The current transformer circuit must never be operated open under any circumstances, as this can lead to personal injury and damage to the device.

Avoiding physical injury

- · When working with the unit, note all safety notices attached to the packaging and the unit.
- Check whether there is no damage to the unit, any accessories and the power supply both before commissioning and regularly during continuous operation. If there is any doubt, have a qualified electrician check whether the technology is sound.
- If the unit is damaged or needs to be repaired, always leave this to authorised personnel.
- Make sure the accompanying power supply is used and the unit's mains voltage is identical to the mains voltage in your country.
- The Energy Manager may only be operated with the power supply provided or via the internal 24 V
 power supply from the TESVOLT PCS. Any damage caused by using a different power supply is not
 covered by the manufacturer/supplier guarantee.
- Do not open either the Energy Manager or the power supply! Removing or damaging the casing can expose live components and compromise the functioning of the unit.

Avoiding damage to the TESVOLT Energy Manager

- The Energy Manager has a protection class of IP20 and may only be installed indoors in dry, dustfree environments. Protect the unit from dust, moisture, aggressive substances and vapours.
- The ambient temperature must be between 0 °C and +50 °C.
- Do not touch any electronic components or connections on the unit as this may damage or destroy them. Ground yourself before working on the unit.
- If the unit or power supply is damaged or destroyed, it must be decommissioned immediately by a specialist.
- Only operate the unit if it is in a technically perfect condition.
- If there are error messages on the unit, always contact service@tesvolt.com or the TESVOLT Service Line +49 (0) 3491 87 97 200 directly.

2.2 DATA SECURITY

In order to be able to make full use of all the functions of the TESVOLT Energy Manager, it must be connected to the local network and the internet. Although the communication path between the Energy Manager and internet services is secured in accordance with the latest technology, there are security risks involved in connecting to a network or the internet: Third parties could access your network and misuse your energy data. Please take the same care with passwords that allow access to your network as you do when protecting data on your computer.

You should therefore operate the TESVOLT Energy Manager in a separate area on your network (subnet or VLAN) or on a completely separated network, e.g. using an LTE router. In any case, the network should be protected by a firewall. Remote access should only be possible via an encrypted VPN connection.

Protecting your personal energy data is extremely important to us. The myTESWORLD platform is therefore permanently kept up to date with the latest security technology in order to ensure that energy data can be retrieved only by the owner and participants who are entitled to do so.



NOTE: The data collected by the Energy Manager may deviate from the electricity meter data, depending on how the data is captured. If we read existing power measurement meters, the meter readings we use correspond to those of the meters. However, data from the Energy Manager are not to be used for billing purposes.

3 PREPARATION

3.1 REQUIRED TOOLS AND RESOURCES

TOOL/RESOURCE	USE
0.4 x 2.5 screwdriver	Connection to the terminal blocks
Laptop	Configuration of the TESVOLT Energy Manager
Wireless router if necessary	If there is no communications infrastructure available, an easy way to carry out initial configuration is with a wireless router.
Patch cable	Connection of laptop and TESVOLT Energy Manager and to router/LAN.
At least 3x IP addresses for LAN 1 network	You need at least 3 IP addresses to configure and commission the TESVOLT Energy Manager. If dynamic addresses are not assigned using DHCP, you must have static addresses set up.


3.2 PREPARATORY WORK

For all installed components:

- Update firmware to the most recent version,
- Activate Modbus TCP (e.g. SMA),
- Activate external control (e.g. Fronius).

3.3 PREPARATION FOR INSTALLATION

The TESVOLT Energy Manager is installed in control cabinets or in small installation distributors on a 35 mm mounting rail as per DIN 43880. It can be installed in any position.



4 TECHNICAL DATA







TECHNICAL DATA FOR THE TES	SVOLT ENERGY MANAGER
Electrical connection	
Voltage	12–24 V_{DC} (-15%/+20%), protected against reverse polarity
Current (at U = 24 V _{DC})	max. 210 mA
Power	max. 20 W (incl. max. 1 A USB power supply)
Interfaces	
2 x RJ 45 10/100 Ethernet (with independent MAC addresses)	2 x Ethernet 10/100 Mbit/s, RJ45
Micro USB jack (exclusively for image transfer to eMMC)	1 x micro USB (exclusively for image transfer to eMMC)
RS-485	1 x RS-485, terminal connections
USB	2 x USB 2.0 type A (total power draw from both jacks max. 1 A)
Micro HDMI	HDMI 2.0a (4K)
Other:	1 x PiBridge system bus, 1x ConBridge system bus
Terminal blocks/connections	
Wire cross-section	0.5-1.5 mm², 28-16 AWG
Stripping length of the cable	7 mm
Ambient conditions	
Operating temperature	-25 to +55°C
Max. (air) humidity at 40°C	max. 93% (non-condensing)
Storage/transport temperature	-25 to +85°C
Protection class	IP 20
Miscellaneous	
Casing dimensions (H x W x D)	96 x 45 x 110.5 mm
Weight	197 g (224 g incl. plug)
Place of installation	Indoors
Type of installation	35 mm mounting rail
Standards	EN 61326-1:2013, EN 55011 group 1 class A, EN 55011 group 1 class B

5 TESVOLT ENERGY MANAGER

5.1 SCOPE OF DELIVERY




5.2 CONNECTIONS AND SETUP OF THE TESVOLT ENERGY MANAGER




Description of the connections


X2 DIO



X2 KC4S



LED-Indicator DIO




3 IN

4

(5) 6

02/12



1 Output 2

2 Output 4

3 Output 6

4 Output 8

(5) Output 10

Output 12

6 7 Output 14

(8) Input 14

9 Input 12


10 Input 10

Input 8


(12) Input 6

 \bigcirc Input 4

(14) Input 2



01/11



Output 1

2 Output 3

(3) Output 5

4 Output 7

(5) Output 9

6 Output 11 7 Output 13

8 Input 13

9 Input 11


Input 9

Input 7

Input 5

(13) Input 3

(14) Input 1



LED-Indicator KC4S




2 A1 no function

3 A2 no function

4 WD no function


(5) REL relay (OFF = contact open/green = contact closed)

6 A3 no function




- ① Activity LED indicates network connection activity.
- ② Link LED indicates network connection status.

RS485




X4 DIO



- 2 0 V
- (3) WD (not used, preinstalled bridge to (2))
- 4 Functional ground


X4 KC4S



- 1 24 V
- 2 0 V
- WD (not used, preinstalled bridge to 2)
- 4 Functional ground

5.3 TESVOLT ENERGY MANAGER USER INTERFACE

The TESVOLT Energy Manager is operated via a graphic user interface. The display is viewed in a browser. The unit can be configured from the user interface and live values and other data can be read from here.



6 INSTALLING THE UNIT




NOTE: When connecting new units, the Energy Manager must be taken out of operation and be voltage-free.

6.1 NETWORK STRUCTURE

Note that in particular the LAN 1 network is separated from the internal network, as with a guest network. A firewall or VLAN can also be used here. An alternative option is separate internet access, e.g. via an LTE router.


TS-IHV80

The illustration shows a typical communications architecture setup with a TS-I HV 80.




SMA STPS X

The illustration shows a typical communications architecture setup using an SMA STPS X inverter together with a TESVOLT TS HV 30-80 E storage system.



SMA Inverter Manager

The illustration shows a typical communications architecture setup with an SMA Inverter Manager. This allows an SMA STPS 60 to be used with a TESVOLT HV storage system, for example.



6.2 MAXIMUM CABLE LENGTHS FOR TESVOLT ENERGY MANAGER INPUTS AND OUTPUTS



NOTE: Disruption to data transfer due to insufficient shielding of energy cables

Insufficient shielding of energy cables produces an electromagnetic field during operation which can disrupt data transfer through network cables. When laying network cables without separators, a minimum distance of 200 mm must therefore be maintained from unshielded energy cables. When laying network cables with separators, the following minimum distances apply depending on the separator material: aluminium 100 mm, steel 50 mm.

INPUT/OUTPUT	MAXIMUM CABLE LENGTH
Power supply	3 m
Digital inputs/outputs	10 m
Ethernet 10/100Mbit	30 m
RS-485	30 m

6.3 TOP HAT MOUNTING RAIL INSTALLATION

Install the TESVOLT Energy Manager in a control cabinet or small installation distributor on a 35 mm mounting rail as per DIN 43880. It can be installed in any position. Note the installation dimensions shown in the illustration in section "3.3 Preparation for installation" on page 9 as well as the maximum cable lengths in the previous section.

6.4 CONNECTION OF KC4S AND DIO-MODUL



WARNING! The DIO module must only be connected on the left side using the black PiBridge plug. If a module is connected on the right side (the connect port), the units may be damaged or destroyed.





Connect the PiBridge to the PiBridge connections on the KC4S and DIO module as shown.

6.5 24 V POWER SUPPLY




WARNING! Do not connect the KC4S to the power supply until all other units and connectors have been connected. If the KC4S is already connected to the voltage source and a unit is connected later, it is possible that the KC4S and/or connected units may be damaged or destroyed.



WARNING! Make sure that the wiring is correct, otherwise the KC4S and/or connected units may be damaged or destroyed.

Connect the 24 V power supply of the KC4S and the DIO module. If possible, consolidate the connections for the functional ground and connect them to an appropriate grounding point. Please note that the supply line must be switchable. The fuse protection should be 3 A.



Operating voltage	24 V
Power	max. 20 W
Wire cross-section	0.5-2.5 mm ² , 28-16 AWG
Cable length	max. 3 m
Stripping length of the cable	7 mm

6.6 NETWORK

Connect the LAN A connection of the Energy Manager 6 for the internet connection to the LAN 1 switch, and then connect the LAN B connection (H) to the LAN 2 switch (dedicated Modbus network). If units cannot be connected to the dedicated network (LAN 2), they can also be connected to the LAN 1 network. When configuring the DHCP server, make sure that an infinite lease time is set for the IP of the connected units of the topology. Otherwise, a connection failure of a ModBus unit may result in it receiving a new IP from the DHCP server and it will no longer be possible to control the units with the Energy Manager. If you do not use a DHCP server as recommended, a fixed IP address must also be assigned to all units manually.

Transmission speed	10/100 Mbit
Cable length	max. 30 m


6.7 RS-485

The integrated RS-485 interface (1) (1) (3) can be used, for example, to connect Modbus RTU units. Terminal assignment can be found in the section "Description of the connections" on page 12 et seg. Please note the technical specifications for the connection.

Wire cross-section	0.5-1.5 mm ² , 28-16 AWG
Cable length	max. 30 m
Stripping length of the cable	7 mm
Terminal tightening torque	0.2 Nm

6.8 DIGITAL OUTPUTS

The digital outputs $\bigcirc \bigcirc \bigcirc$ and $\bigcirc \bigcirc$ can be used, for example, to connect relays (e.g. for heat pumps that are smart grid ready) or NA box signals. Terminal assignment can be found in the section "Description of the connections" on page 12 et seq. Please note the technical specifications for the connection.



No. of channels	14
Max. current	500 mA in total
Max. voltage	24 V _{DC}
Wire cross-section	0.5-1.5 mm ² , 28-16 AWG
Cable length	max. 10 m
Stripping length of the cable	7 mm

6.9 CONNECTION OF THE ENERGY MANAGER



DANGER! Life-threatening voltage

- Connect the Energy Manager when it is voltage-free.
- Make sure the unit cannot be switched back on.
- Do not supply the 24 V power supply unit with 230 V mains voltage until the final step.
- Connect the 24 V power supply in accordance with section "6.5 24 V power supply" on page 20.
- Now, connect the grid connections of the TESVOLT Energy Manager and all units connected in the network to the switches according to sections "6.1 Network structure" on page 16 and "6.6 Network" on page 20. Check all cables beforehand with a network tester. For use with a TS-IHV 80, please refer to the "Establishing communication links" section in the Installation and Operating Manual for the model.

7 UNIT SETUP

In systems with TESVOLT battery inverters, please follow the commissioning instructions provided in the relevant installation and operating manual.

7.1 SWITCH ON THE TESVOLT ENERGY MANAGER

Follow the steps below to switch on the TESVOLT Energy Manager:

- Connect the 24 V power supply.
 - > The LED of the POWER button flashes during start-up.
- > The LED of the POWER button lights up continuously when the system has successfully started up.



NOTE: Email notification of inactivity

If the unit has been inactive for more than 45 minutes, it will not send a heartbeat to the myTESWORLD portal. In this case, you will receive an email prompting you to take action.

When you receive this email, please check that the unit has started up correctly and is connected to the network.

Check activity and connectivity

Follow the steps below to check whether the TESVOLT Energy Manager has correctly started up and is connected to the network:

1 Check that the power LED on the unit is lit up.

The power LED is not lit up:

- Check the voltage supply (see "6.5 24 V power supply" on page 20).
- If necessary, disconnect and restore the power supply (see "6.9 Connection of the Energy Manager" on page 21).
- The unit may be defective. Contact TESVOLT Service.

The power LED is lit up:

- Go to 2 and follow the instructions.
- Check that the network LEDs on the LED inputs are flashing (see "Description of the connections" on page 12).

The network LEDs are not flashing:

- Check the network cabling on the unit and correct it if necessary (see "6.6 Network" on page 20).
- Restart the unit if necessary.
- The unit may be defective. Contact TESVOLT Service.
- · The network LEDs are flashing:
- Go to 3 and follow the instructions.

Check the unit connectivity in the user interface (see "Checking network configuration and status" on page 28).

Unit not connected:

- Check network settings such as firewall and IP.
- Check internet availability.
- Contact TESVOLT Service if necessary.

The unit is connected:

• It is operating correctly.


7.2 SCANNING THE NETWORK ENVIRONMENT

Scan the network environment using an IP scanner, e.g. the Advanced IP Scanner. In the IP scanner results list, double-click on the IP address of the TESVOLT Energy Manager (manufacturer: Kunbus GmbH), or copy the IP address and paste it in the browser address bar.


7.3 SETTING UP A USER FOR THE FIRST TIME

All TESVOLT Energy Manager hardware devices delivered from 1 August 2025 onwards have a pre-installed licence (with the new part number 106248). This means that the licence key previously communicated separately by e-mail no longer has to be brought to the construction site for setup.

- **NOTE:** From now on, you will need the PUK to set up the TESVOLT Energy Manager. For FORTON, this code can be found on a black sticker with white lettering on the back of the cabinet door (see section 6.7 of the TESVOLT FORTON operating manual). If you have received the TESVOLT Energy Manager separately for installing yourself or have purchased another TESVOLT storage system, this code can be found on the left-hand side of the TESVOLT Energy Manager housing itself (black sticker with white lettering). It is best to take a photo of it before you install the hardware, because you will no longer be able to see the code afterwards.
- Switch on the 24 V power supply.
- Connect your laptop to the dedicated Modbus network to access the TESVOLT Energy Manager user interface. In the factory configuration, the unit is pre-configured for the use of a DHCP server.



Enter the IP address of the TESVOLT Energy Manager in a browser to access the configuration interface. Click on the "Create/reset login details" button 3. Here you can create a new user and use this to log in after setting up.



On the next page, enter the PUK in the first field ⓐ. For FORTON, this code can be found on a black sticker with white lettering on the back of the cabinet door (see section 6.7 of the TESVOLT FORTON operating manual). If you have received the TESVOLT Energy Manager separately for installing yourself, this code can be found on the left hand side of the housing itself (black sticker with white lettering). If an "initial password" is requested in the first line instead of the PUK, please click on the "Initial password" button to the right of the first line. The interface will then ask you to enter the PUK. Enter any user name in the input field ⓑ and a password for the user in the fields ⑤. The password must contain at least one upper-case and one lower-case letter, as well as a number and a special character. Confirm your entry by clicking on "Create Account" ⑥.






You will be redirected to the previous login interface. Enter the user name you have just created in field and the password in the second field and then confirm the login by clicking on "Login" (c.

7.4 INSTALLATION WIZARD (INITIAL SETUP)

If you are setting up the TESVOLT Energy Manager for the first time, you will be greeted by the installation wizard.



The wizard guides you through the necessary commissioning steps until the Energy Manager is fully

The installation wizard can be operated in four display modes, which can be selected via the icons at the top right of the wizard window:

- (a) Minimised: The wizard is located in the upper part of the window, which makes it easier to operate, especially on devices with a small screen.
- **b** Maximised: All commissioning steps and their progress are displayed.
- (c) Window mode: Normal display mode in which the current commissioning step is shown and its context explained.
- d Closed: The wizard is closed and can be called up again at any time by clicking on the signpost icon in the top right-hand corner of the window.

Each commissioning step has a specific state of progress. An overview of the possible states is shown in the table below.

Open: This commissioning step has yet to be completed. (1) Reopened: This commissioning step must be run again due to changes in another step... 1 Automatically completed: This commissioning step was carried out automatically by the <a>♠ TESVOLT Energy Manager and only needs to be checked. For later: This commissioning step was noted by the user for later review.. Completed: This commissioning step has already been completed by the user. \checkmark

Clicking on the arrow dopens the first area or commissioning step.

To get to the next step, you can either mark the current commissioning step for later review by clicking on the yellow bookmark icon or mark it as complete by clicking on the green tick icon.


The state of progress can be displayed at any time by clicking on the "Maximise" icon **b**.

Once all recommended steps have been processed or marked for later review, the installation wizard is complete and can be closed by clicking on the "Close" icon \bigcirc . To open it again, click on the signpost icon in the top right-hand corner of the window (to the left of the moon and sun icons for switching between light and dark modes).

You can also interrupt commissioning at any time and resume it later. If you interrupt commissioning before completing the wizard, the next time you open the wizard it will open automatically at the point where you last left off.

7.5 FIRMWARE UPDATE

To make sure that your TESVOLT Energy Manager has the latest software version, check whether there is a firmware update and update the device if necessary.




In the page navigation, click on "System Settings" and then on "FW Upgrade". Click once on "Check for new version" (b). You will see the status of the installed firmware (a) at the top right of the page. If the firmware is up to date, there is no need for further action. Otherwise, click on "Upgrade" 🕡 and follow the instructions.

7.6 NETWORK CONFIGURATION


Setting up the network configuration



NOTE: In dynamic network configuration (factory setting), the IP address of the TESVOLT Energy Manager is automatically assigned by the DHCP server. Determining the IP numbers of the Energy Manager and the other units can be very time-consuming. This is a significant drawback especially when it comes to error diagnosis. For this reason, the use of static network configuration is recommended. Note the IP addresses used and what they are used for in a separate document.




If you would like to use a DHCP server (factory setting), in the "Settings" section of the side menu, click on the "System Settings" menu item and then "Network". For the first item "Dynamic or static Network Configuration", click on the option "Dynamic (DHCP)" a. This option enables fully automatic network configuration of the unit, meaning the Energy Manager automatically obtains an IP address, netmask and gateway when the DHCP server is started. You can also configure the following settings: b automatic DNS configuration yes/no. If automatic DNS configuration is set to "no": c primary DNS server, d secondary DNS server. To apply the changes, click on "Save" e.



To adjust the static network settings of the ethernet connection, click on the "System Settings" menu item in the side menu and then on "Network". For the first item "Dynamic or static Network Configuration", click on the option "Static" a. You can now configure the following settings for the static network configuration: b the future IP address of the Energy Manager, t the netmask of the network, the IP address of a gateway (usually the router), primary DNS server, secondary DNS server. To apply the changes, click on "Save" g.

Checking network configuration and status





To check the network settings and the status of the connections and the network, click on "Interfaces" in the side menu and then on the item "Network". In the "Uplink Network" section 📵 you will find the current IP address (IPv4) of the TESVOLT Energy Manager on the second line. In the "Uplink Network Connectivity" section (b) you can see if there is a connection to the internet, if a DNS server is available and if there is a connection to the myTESWORLD platform. The other sections are relevant for servicing.


7.7 RS485 BUS KONFIGURATION (MODBUS-RTU)

Modbus RTU uses the RS485 connection of the TESVOLT Energy Manager. A two-wire (A + B) or threewire (A + B + GND) cable is used for serial communication in a bus system. This means that all devices connected to this bus are connected in series and must be set to exactly the same mode and baud rate in order to be able to communicate successfully with each other serially, i.e. one after the other. Up to 32 devices can be connected via such a bus.



NOTE: Tips for connection problems

- The best signal quality is achieved with shielded twisted pair cables.
- Both data cables must be used consistently at the same jack on all devices. In other words, choose the same jack as "A" and the other as "B" for all devices in the utility grid and connect one and the same data cable to all "A" jacks and the other to all "B" jacks.
- A connected GND line can significantly improve the signal quality and operational reliability of RS485, especially where there are longer distances, different power supplies and a lack of galvanic isolation. However, this is not always absolutely necessary - where short distances and a shared power supply, the system can also operate without one, albeit with an increased risk of disruptions.
- Every TESVOLT Energy Manager already has an activated 120 ohm terminating resistor on the RS485 port.
- If a large number of devices are used on a common bus (max. 32 devices), increasing the baud rate for all connected devices can help improve communication.



Now configure the Modbus RTU interface if your devices use this interface (Modbus RTU). To do this, click on "RS485 Bus" in the "System Settings" side menu. In the "Serial port mode" field (a), select the mode you want this RS485 bus to operate in (number of data bits, parity, number of stop bits). Then set the desired speed at which this RS485 bus should operate in the "Baud rate" field 🕦 (symbols per second). In the "TCP port" field 🕠, enter the port at which the TESVOLT Energy Manager should provide a corresponding Modbus TCP connection. Finally, click on "Save" d.

NOTE: The TESVOLT Energy Manager converts the received Modbus RTU data into Modbus TCP data internally and makes this available internally for its own drivers at a specific port (usually port 1502). For example, if you connect a power measurement meter via Modbus RTU, specify 127.0.0.1:1502 in the input field of the IP and port when configuring the power measurement meter. The internal IP of the TESVOLT Energy Manager is always 127.0.0.1 and "1502" is the port that you entered in the "TCP port" field when configuring the RS485 point. If your energy manager has two RS485 ports, the second port can be configured separately and the devices connected to it can be reached via 127.0.0.1:1602.


2 Then, if necessary, configure the other RS485 port in the same way.


7.8 USER MANAGEMENT


1


Both the TESVOLT Energy Manager (hardware) and the myTESWORLD portal have their own user management. In order to monitor and control a system using myTESWORLD, you must first create a user on the TESVOLT Energy Manager and then in the myTESWORLD portal.

Creating users











To set up an additional user, click on "User Management" in the side menu. In the window this brings up, you can set up additional users using the dialogue box on the right-hand side under "Add user accounts". Enter the relevant name in the field "Username" (a) and the corresponding password in the two following fields (b). Finally, click on "Add" (c) to save the details.

Deleting users




Click on "User Management" in the side menu. Then click on the "Delete" button 1 next to the entry in the user list you wish to delete, and confirm the action in the following dialogue box. The user is now deleted.

Editing users



Click on the user symbol \bigcirc to access the settings for the active user account.




To make changes to the name or password of the current user, you must first enter your password $oldsymbol{\mathfrak{a}}$. You can then enter a new user name for the active account in the field 🕕. If you would (also) like to change the password, enter a new password in the fields \mathfrak{c} . Then click on the "Save" button \mathfrak{d} to save the changes.

Resetting a password



If you have lost your password, user name or both, click on "Forgot your credentials?" 1 on the login page.

2




In the next dialogue box, enter your user name in the field "Username" a or, if you have forgotten it, a new one. In the two fields "Password" b and "Confirm password" b, you must enter your new password. In the field "PUK" the PUK must now be entered. If you did not write down the PUK, you can find the PUK on a black sticker on the left side of the KC4S casing (on the side of the DIO). After entering the PUK, click either on "Create account" d if you also want to set up a new user name, or on "Reset password" if you only need to reset the password.

8 TOPOLOGY SETUP


8.1 SETTING UP LOGICAL DEVICES

The devices whose setup is described in this section are referred to as "logical devices". In contrast, all devices that you will go on to set up in the topology (see section "8.2 Setting the topology" on page 56) are described as "physical devices". Later, logical and physical devices will be linked with each other, as described in the section "Procedure - Adding physical devices" on page 57.


Meter configuration



Log into the TESVOLT Energy Manager and access the page "Existing Configurations" (Meter). In the side menu, click on: "Device Settings" ightarrow "Meter" and then on the button "Add new Meter" $\overline{f a}$



On the window that appears, click on "Choose a model" @ and select the type of meter used from the drop-down menu (e.g. Janitza UMG 604).




Fill in the fields and then click on the "Save" button 1. If you know the IP address of the meter and this is already in operation, you can simply copy the address using the Modbus TCP Assistant, rather than entering it. To do this click on the button b and select the IP address of the meter from the dropdown menu. The address is saved to the clipboard and can be pasted in the field "Modbus TCP Address".




NOTE: If you are using a meter from Janitza or SIEMENS, please note:

- The default value for the port is :502 (e.g. 192.168.29.8:502).
- The default Modbus slave ID is 1. In Janitza meters it can be changed if necessary in the meter configuration.
- The page "Existing Configurations" is now loaded again. If the added meter is already in operation and online, the new meter will appear in the "Online" list after 20 seconds at the latest. If the meter is not yet online/operational, it is found in the "Offline" list.
- [5] The second meter and any additional meters can then be added in the same way. The meter installation location (utility grid transmission/inverter) is assigned during the topology assignment (see section "8.2 Setting the topology" on page 56 et seq.) and for TS-I HV systems with backup functionality, additionally in the configuration of the PCS.


Battery inverter configuration



Log into the TESVOLT Energy Manager and access the page "Existing Configurations" (Inverter). In the side menu, click on: "Device Settings" \rightarrow "Inverter" and then on the button "Add new Inverter" \bigcirc



On the page that appears, click on "Choose a model" 1 and select the type of inverter used from the drop-down menu (e.g. TESVOLT PCS).



Fill in the fields and then click on the "Save" button 1. If you know the IP address of the inverter and this is already in operation, you can simply copy the address using the Modbus TCP Assistant, rather than entering it. To do this click on the button 🕦 and select the IP address of the inverter from the drop-down menu. The address is saved to the clipboard and can be pasted in the field "Modbus TCP Address".




NOTE: SMA Data Manager

You can also use the configuration wizard to set up the SMA Data Manager.

1

Example - configuration of the TESVOLT PCS



- Show all Configurations > Back to overview of battery inverters
- **Select a model** > Drop-down menu to select the type of battery inverter
- ModbusTCP Address of Inverter CCU (anybus) > Enter the Modbus TCP address of the battery inverter here. This is stored on the SD card and is also shown on a sticker on the CCU.
- **Modbus Slave ID of Inverter CCU (anybus)** > Modbus slave ID of the inverter. The default value is "0".
- Ploat charging power in W > Enter what power should be used for float charging the batteries (e.g. 1,000 W per IPU plus 1,000 W if a transformer is present).
- **f** Power-Limit-Mode is active > Using the power limit function, the inverter can limit the power via the MIO (e.g. physical peak shaving with control speed <1 ms). However, a specific system configuration is required for this.
 - If necessary, please contact the TESVOLT Service Line +49 (0) 3491 8797-200.
- Lower power-threshold for Power-Limit-Mode in W > The default value is "0".
- Upper power-threshold for Power-Limit-Mode in W > The default value is "0".
- i Select a BMS (optional) > Drop-down menu to select a BMS
- **i** Select a NA-Box (optional) > Drop-down menu to select the NA-Box used
- (charging power limit in W > Limits the charging power to the value set (positive value).
- Discharging power limit in W > Limits the discharging power to the value set (negative value).
- m Number of IPUs > Enter the number of active IPUs.


- Q-Control > Configuration of the Q-Control (FUNDFREQMODE_DISABLED, FUNDFREQMODE_QREF, FUNDFREQMODE_PCF, FUNDFREQMODE_VREF)
- Symmetry Mode > Configuration of the Symmetry Mode (on/off)
- Harmonic Mode > Configuration of the Harmonic Mode (on/off)
- 1 Disable ECO Mode > If the fastest response times in the millisecond range are required, ECO Mode must be disabled.
- Save
- Enter the values in the fields on the screen according to the explanations above.
- Then click on "Save" 1 to apply the settings.
- Where "TESVOLT EMS" is selected in Step [1] (i), use the following settings:



- a Modbus TCP Address of Battery (Master) APU > Enter the Modbus TCP address of the battery (master) APU here. You can display the IP address via the APU display (2nd page). Remember to enter port :502.
- **1** Modbus Slave ID of Battery (Master) APU > Enter the slave ID of the battery (master) APU here. The default value is "0".
- Lower SoC float charge threshold in % > The threshold for the float charge defines the lower limit of the depth of discharge protection zone as a percentage of the state of charge. If it goes below this value, the battery system recharges itself back to the upper limit (d), at a power level corresponding to the value set for "Float charging" in Step [1] @.
- Upper SoC float charge threshold in % > Defines the upper threshold of the depth of discharge protection zone as a percentage of the state of charge. Above this value, the float charging is stopped and the battery system switches to standby mode.

Example - TESVOLT FORTON configuration


TESVOLT FORTON battery storage systems are configured in the TESVOLT Energy Manager as battery inverters. The type of installed inverter (KACO or SMA) is irrelevant for the configuration.



- Select a model > drop-down menu for selecting the type of battery inverter
- b IP & port of the IoT gateway > IP number of the IoT gateway of the FORTON; the port is always 1884
- c Disable TLS > if enabled, communication for the MQTT connection is unencrypted (default)
- d Do not transfer MQTT user name > if enabled, no user name will be transferred to the MQTT broker
- MQTT user name > enter "TEM" as the MQTT user name
- **f** Do not transfer MQTT password > if enabled, no password will be transferred to the MQTT broker
- **g MQTT password** > enter "Wendeware" as the MQTT password
- **h** Lower threshold for trickle charging in % > the storage system is charged as soon as the state of charge (SoC) falls below the specified value
- i Upper threshold for trickle charging in % > the storage system is charged until the state of charge (SoC) exceeds the specified value
- **j Trickle charge in W** > amount of trickle charge in watts
- **R** Save
- Enter the values in the fields on the screen according to the explanations above.
- Then click on "Save" h to apply the settings.

Example - SMA STPS X configuration






- Show all configurations > Back to the inverter overview
- **b Select a model** > Drop-down-menu to select the type of battery inverter (depending on the power rating SMA Sunny Tripower Storage STPS30 or SMA Sunny Tripower Storage STPS50)
- Modbus TCP address > ModbusTCP address of the SMA STPS X (default: Port 502, you must enter the port!)
- Slave ID > Slave ID of the SMA STPS X (default: 3)
- Lower SoC trickle charge threshold in % > The threshold for the trickle charge defines the lower limit of the depth of discharge as a percentage of the state of charge. If it falls below this value, the battery system recharges itself back to the upper limit (1), at a power level corresponding to the value set for the trickle charge g. (Default: 1%)
- (f) Upper SoC trickle charge threshold in % > Defines the upper threshold of the depth of discharge protection zone as a percentage of the state of charge. Above this value, the trickle charging is stopped and the battery system switches to standby mode. (Default: 3 %)
- g Trickle charge power in W > Enter the power to be used for trickle charging the batteries (default: 1,000)
- Save
- Enter the values in the fields on the screen according to the explanations above.
- Then click on "Save" 1 to apply the settings.
- **NOTE:** When the upper SoC trickle charge threshold has been reached, trickle charging is stopped until the upper SoC trickle charge threshold is exceeded again. As a result of the battery inverter's self-consumption, the battery falls to the lower SoC trickle charge threshold if there is no charging. It recharges itself back to the upper SoC trickle charge threshold at a power level corresponding to the value set for trickle charging.

Example - SMA Inverter Manager configuration





- Show all configurations > Back to the inverter overview
- **b** Choose a model > Drop-down menu to select the type of battery inverter
- Modbus TCP address > ModbusTCP address of the SMA Inverter Manager (IMPORTANT: Port 502)
- **1 Slave ID** > Slave ID of the SMA Inverter Manager (default: 125)
- Has PV > Must always be set to "Off" (tick box not ticked)
- f Has battery > Must always be set to "On" (tick box ticked)
- **g Lower SoC trickle charge threshold in % >** The threshold for the trickle charge defines the lower limit of the depth of discharge protection zone as a percentage of the state of charge. If it falls below this value, the battery system recharges itself back to the upper limit 1, at a power level corresponding to the value set for "Trickle charging" (1). (Default: 1 %)
- 1 Upper SoC trickle charge threshold in % > Defines the upper threshold of the depth of discharge protection zone as a percentage of the state of charge. Above this value, the trickle charging is stopped and the battery system switches to standby mode. (Default: 3 %)
- i Trickle charge power in W > Enter the power to be used for trickle charging the batteries (default: 1.000)
- Save
- Enter the values in the fields on the screen according to the explanations above.
- Then click on "Save" j to apply the settings.
- NOTE: When the upper SoC trickle charge threshold has been reached, trickle charging is stopped, until the upper SoC trickle charge threshold is exceeded again. As a result of the battery inverter's self-consumption, the battery falls to the lower SoC trickle charge threshold if there is no charging. It recharges itself back to the upper SoC trickle charge threshold at a power level corresponding to the value set for trickle charging.


Settings in the SMA Inverter Manager



NOTE: The SMA STPS-60 battery inverter must already be commissioned and updated to the latest software version (2.05.007, released 19 September 2024).



NOTE: The software version of the LCS tool must match the firmware installed on the SMA STPS.




Log in to the LCS tool as "Installer". The password can be found on the device unless it has been changed.

- [2] Check the firmware version of the inverter. Do this by clicking on the right arrow keys in the inverter display until "communication version" is displayed. The version of the LCS tool can be gueried using the "i" symbol in the top right corner of the programme window.
- If the firmware versions do not match, carry out any necessary updates to make them match.
 - # IVMZyk1 139F0215020901M367 ● Status 🚇 Logs 🖺 Reports 🗠 Setup 🗲 Service Date and Time Portal Upload Inverter Param Safety Offset: Limited Export Enabled Peak Load Shaving Time Of Use


Open the "Power Management" page from the "Setup" menu. Do not change the grid meter settings. Please note that with the Janitza 604 the maximum number of reading devices is five. For control via Modbus, all applications 3 on this page must be set to "Off". No Modbus commands are executed if time of use or peak load shaving are active. "Limited export enabled" is already deactivated in the normal configuration of the Inverter Manager.




NOTE: A personal Grid Guard code is required for the following configuration steps. You must request this code from SMA.




Go to the "Service" menu on the "Grid Guard" page and enter your personal Grid Guard code.



Successful entry is indicated by a message and a symbol 1 in the top right corner:



Before making the next changes, please stop the inverter(s)using the "Plant Stop" button 1. If the inverter(s) is/are switched off, the button is labelled "Plant Start".



Go to the "Inverter Parameters" page via the menu item "Setup". Loading these parameters may take several minutes. On this page, open the "Support Settings" (a) section and then the "Immediate controls" subsection 🕩.


Change the following parameters (marked green in the figure):

Parameter New value

Ramp In (RmpIncTmm ONLINE) 1200%/min


Maximum active power reduction rate after external setpoint change (RmpDecTmm_EXT) -1200%/min Maximum active power increase rate after external setpoint change (RmpIncTmm_EXT) 1200%/min Save the changes by clicking the "Save" button. The inverter will then restart.





We recommend using a fallback setting to protect the battery against deep discharge in the event of a prolonged communication interruption between the SMA Inverter Manager and the TESVOLT Energy Manager. To do this, go to "Plant Fallback" in the "Setup" menu and set the switch to "Yes".





Once activated, you can define the interruption period "Timeout" after which the inverter should react. We recommend the following settings:

Parameter	Value
Timeout	60 s
P ref	-1% (corresponds to charged with 1% of available inverter power)
Q ref	0
PF ref	1 (Power Factor)


Controlling the inverter

To ensure safe work on the unit, you can control and switch off the selected inverter.


For example, you can activate automatic start/stop mode in the inverter configurations.

Open the unit configurations for the relevant inverter by clicking on "Inverter" in the side menu under "Unit Configurations".






To control the inverter, click the "Control" button 1.




- Model > Display inverter model number
- f Status info > Display status information
- g Last value > Activation of manual start
- Last value OPEN > Unit is off activation of manual start/stop
- Last value CLOSED > Unit is on activation of start/stop.
- Check the box next to "activate manRstr" (g) to activate manual start. Then click on "Set" (h).
- Or tick the box next to "activate manStrStop" 10 to activate the manual start stop. Then click on "Set" **(1)**

- Or tick the box next to "activate StrStop" () to activate the automatic start/stop mode. Then click on "Set" ().
- **NOTE:** For safety reasons, the settings made here override the settings in the energy services of the switch (see section "Switch/set point" on page 80).


Charge point configuration



Log into the TESVOLT Energy Manager and access the charge point overview ("Existing Configurations") via the side menu: "Device Settings → Charge-Point". Then click on the "Add new Charge-Point" button ③.



On the page that appears, click on "Choose a model" a and select the type of charge point used from the drop-down menu (e.g. Mennekes Amtron). Then complete the fields.




Finally, click on "Save" (1), to apply the settings.

Digital outputs (GPIO) configuration


[3]

"GPIO" refers to the digital outputs of the TESVOLT Energy Manager (🕕 🛈 ... 🧷 and 🕒 🛈 ... 🗘). The unit has a total of 14 of these outputs, which allow relays for load control or generation control (e.g. for heat pumps that are smart grid ready) to be switched separately. Further information can be found in the section "6.8 Digital Outputs" on page 21.




Log into the TESVOLT Energy Manager and access the GPIO overview ("Existing Configurations") via the side menu: "Device Settings \rightarrow GPIO". Then click on the "Add new GPIO" button \bigcirc

2



On the page that appears, click on "Choose a model" a and select "Generic GPIO TEM Output" from the drop-down menu.



Complete the fields.


- 1 Show all configurations > Back to the GPIO overview
- **b** Modbus TCP assistant
- C Select a model > Currently only generic GPIO TEM output
- **Output** > Digital output of the TESVOLT Energy Manager to be used
- Device name > Device name can be freely selected for the device to be switched (Warning: the unit cannot be renamed again later.)
- **f Hold-time "ON" in s** > Enter the amount of time the output will stay ON before it is possible to switch it OFF again
- **g Hold-time "OFF" in s** > Enter the amount of time the output will stay OFF before it is possible to switch it ON again
- Save
- Reset
- Then click on "Save" 1 to apply the settings.

Digital input (GPIO) configurations


The digital and potential-free inputs on a TESVOLT Energy Manager can be used to control the EMS. As soon as there is a signal at a GPIO input, it can be used to determine the outcome of a decision in a decision tree, to control generators/consumers through energy services or for calculations, e.g. in formula blocks. The switching of this input can determine the use of strategies, the power level setting points or other calculations. For this purpose, a specific input is defined which can then be selected in all "Simple Sensors" fields. This enables the targeted use of key switches on wall boxes, control panels in production halls and much more.

For information on connecting the digital inputs of the Energy Manager, see section "5.2 Connections and setup of the TESVOLT Energy Manager" on page 12.


To read and use the GPIO input, proceed as follows:



Add a new GPIO by selecting Device Configuration > GPIO from the menu on the side and then clicking on "Add GPIO" 1.




Select "Generic GPIO Input Amperix Input" under model selection 1




Under input 1 select one of the available inputs. Under device name 1 enter a name that helps you recognise it. Click "Save" to complete the setup.


Container configuration



Log into the TESVOLT Energy Manager and access the container overview ("Existing Configurations") via the side menu: "Unit Configuration \rightarrow Container". Then click on the "Add container" button \bigcirc



On the page that appears, under "Choose a model", select 1 "TESVOLT Container TPS" from the dropdown menu.



Complete the fields.

3


- 1 Modbus TCP Address > Here enter the Modbus TCP address and port (:502) of the container.
- (default: 1) Unit ID > Modbus TCP unit ID (default: 1)
- c Unit name > Freely selectable name for the unit (warning: the unit cannot be renamed again later.)
- Then click on "Save" (1) to apply the settings.
- **NOTE:** Topology settings Once the unit is configured, the corresponding physical unit in the topology of the TESVOLT Energy Manager must be assigned to the container. For assignment and further procedures for configuring the topology, please refer to section "Procedure – Adding physical devices" on page 57.

Configuring a heat pump


Heat pumps can be controlled by the TESVOLT Energy Manager via its SG Ready ("Smart Grid Ready") interface. This standardised interface uses two switchable contacts via which up to four states can be assigned to devices (SG-Ready operating state).

OPERATING STATE	CONTACT A	CONTACT B
1	ON	OFF
2	OFF	OFF
3	OFF	ON
4	ON	ON


Table 8.1. Positions of the contacts in the different SG-Ready operating states



To add a new heat pump, click on "Heat pump" under "Device configuration" in the side menu and then on "Add heat pump" (a)



Now select the item "SG-Ready-GPIO" from the drop-down menu.



Next, configure the settings for your heat pump..

- (a) "Show all configurations" > return to the overview of the heat pumps configured in the system
- **b** "Device name" > a uniquely identifiable name must be given
- c "Maximum power in W" > maximum electrical power (draw) of the heat pump
- d "Minimum waiting time after power-off in minutes" > Period of time in minutes for which the GPIO outputs remain switched to "OFF" before it is possible to switch them back to "ON".
- (e) "Minimum waiting time after power-on in minutes" > Period of time in minutes for which the GPIO outputs remain switched to "ON" before it is possible to switch them back to "OFF".
- f "Output 1" > Select which GPIO output is to be assigned to SG-Ready contact A.
- g "Output 2" > Select which GPIO output is to be assigned to SG-Ready contact B.
- (h) "Operating states" > Selection of SG-Ready operating states supported by your heat pump.
- i "Save" > Save changes

[3]


4 4: After you have configured the settings, click on "Save" ①.

Configure external specification


The marketer interface sends specifications for PV regulation (direct marketing) and for battery charging and feed-in (flexibility marketing) to the energy management system. The Energy Manager implements these specifications accordingly.

The TESVOLT Energy Manager transmits the following system statuses to the marketer interface:


- Battery SOC (in %)
- Battery power
- PV output
- Grid output
- Calculated power target values/set points



To add a marketer interface, click on Device Configuration > External Specifications in the side menu and then on "Configure External Specifications" (a).



In the drop-down menu (a), select "TESVOLT AG marketer interface".




Then enter the IP address of the Energy Manager in the "List Address" field along with the specification for the port ":1505". Finally, click on "Save" **b**.



NOTE: You still need to create an appropriate "expert strategy" (or customise an existing one) and activate it or integrate it into a decision tree in order to use the marketer interface.

8.2 SETTING THE TOPOLOGY

Compatible devices such as meters, battery inverters and charge points have been installed, connected to the TESVOLT Energy Manager and configured in terms of software, as described in the previous section "8.1 Setting up logical devices" on page 33 et seq. This also goes for devices that will be controlled by means of the digital outputs (GPIO), where applicable. Now the TESVOLT Energy Manager must be told how these logical devices stand in relation to each other (e.g. Battery Inverter 1 is connected to Battery 1 and measured by Meter 2). This is one of the purposes served by the topology, but it is also a requirement for accurate visualisation in the myTESWORLD portal and for many energy services.



In order for it to be able to configure and display the relationships between the logical devices, "physical devices" are set up in the Energy Manager topology configuration. These devices are later displayed 1:1 in the myTESWORLD system visualisation. Each physical device must be measured by at least one meter. This does not mean that every physical device requires its own meter, but that its consumption must be able not only to be measured but also clearly identified.

Meter requirements

Absolute requirements:

- There are at least as many meters as physical devices.
- All physical devices are measured by at least one meter.
- It must be possible to clearly identify the power of each physical device. For example, it will not work if Battery 1 and Battery 2 are only ever measured together (or not at all) by all meters.

Conditional requirements:

There must be a utility grid transmission meter, or else the visualisation in myTESWORLD will be limited.



NOTE: Where they exist, internal meters in devices such as inverters can be used, provided that the devices are connected to the TESVOLT Energy Manager by Modbus. However, please be aware of the following important restriction. Not every internal measuring device is suitable for use as a meter for power measurement.



If you want to use the internal meter in this kind of device, it will alert the Energy Manager. In general we advise against the use of these meters within the topology.

Actuator requirements

For implementing energy services, the behaviour of logical devices (which are not meters) is controlled at specific measuring points in accordance with a defined strategy. These logical devices are known as actuators.


Absolute requirements for actuators:

- Every actuator that is to be used in the energy services must be configured in the topology! The only exception to this is devices controlled via the digital outputs (GPIO). Missing configurations are not recognised by the TESVOLT Energy Manager.
- Two actuators must not affect the same device. The only exception to this is devices controlled via the digital outputs (GPIO).


Procedure - Adding physical devices




NOTE: We recommend mapping out a circuit diagram of the topology on which all significant system components are represented. As well as the designation for the topology, also note down important parameters such as maximum currents. If you have planned to use SoC-dependent decisions within the framework of a decision tree, it is sensible to create a diagram for this showing the allocation of the capacity of the battery inverter for the various energy services including the respective SoC thresholds.



Log into the TESVOLT Energy Manager and in the side menu under "Settings" select "Energy Manager" \rightarrow "Topology" \bigcirc The next steps are first to select the devices in your system in the left-hand column "Supported Device Types" 📵 by clicking on the [+] button, causing them to be added to the right-hand column "Your Devices" (1). When adding the physical devices, it is best to proceed in order from top to bottom.




To set up a battery, find the item "Battery" in the "Supported Device Type" list and click on the [+] button at the end of the line 📵 . You will now find the item "Battery 1" 📵 in the "Your Devices" list.



To set up a PV installation, find the item "PV" from the "Supported Device Type" column and click on the [+] button of the item 📵 . "PV 1" will now appear under "Your Devices" 👈



NOTE: Power used by unspecified consumers (e.g. household electricity), which is only recorded by the utility grid transmission meter (i.e. the sum of the loads not assigned to a physical device), is automatically assigned to "User 1" by the system. Even though it does not refer to a device in the traditional sense, "User 1" must be set up as a physical device, as this represents unspecified consumption in the middle of the circle of the system visualisation (a) in the myTESWORLD portal. In accordance with the principle outlined above, users must also be measured by at least one meter and if no specific measurement is taken, calculation is not possible. If more than one user is set up, the additional users $oldsymbol{\mathfrak{h}}$ are positioned alongside the other physical devices outside the circle in the visualisation.



To set up a user, select the item "User" from the "Supported Device Type" list and click on the [+] but-4 ton at the end of the line. You will now find the item "User 1" in the "Your Devices" list.



In front of each entry in the "Device Assignment" list there is a symbol. The symbols provide information about the logical device type and the colour gives information about the configuration status:



Unconfigured device




Device



Meter

The colour of the entry also provides information about the status of the respective logical device. Yellow entries denote devices that are not yet assigned, while green entries are assigned.



Now assign all devices that are not meters. Meters can be recognised by their names, which start with the name of the manufacturer and/or with "mtr" and are followed by a combination of numbers and letters. Click on the first non-meter device to select and assign it. When the entry is expanded, click on the drop-down menu that is now visible 1



You will now see a drop-down menu 📵 with the devices you set up previously. Click on one of the devices to select and assign it. The warning icon at the start of the entry changes to a device symbol if the assignment is successful, and the colour changes from yellow to green (as does the colour of the word "Configure" at the end of the line).

8 Now assign the remaining devices in the same way.


Meter configuration

2

1 Note down the serial numbers of the meters installed in the system. They are needed for further configuration to identify and assign the meters. The serial number of the meter is part of its designation (e.g. the 8-digit number for Janitza meters).




First, find the entry for the meter of the utility grid transmission point. Click on the list entry to open it. Tick the square box 📵 next to "Grid Meter" by clicking on it. The grid meter is defined as the sum of the power levels of all physical devices at the grid connection point.




Next, select and open the battery storage system meter 1 from the list. Click on the drop-down menu under the label "Assign devices to:" and select the item "Battery 1" by clicking on it.

4 Then, one after another, select and open any other meters present in the system. Then click on the field labelled "Choose a Device" and select all devices that, viewed from the grid connection point, come behind the relevant meter and are recorded by it.



If you want to use a device's internal meter, click on its entry to expand it. Next, click on "Expert mode" **a**

6



In the expert view, additional configuration options are visible. Tick the "Use internal meter" option a In the "Assign devices to:" section that now appears, select which device is measured by the internal meter (b) (normally the same physical device that this logical device is assigned to).

7 Finally, assign the appropriate meters and devices to all positions not yet assigned in the topology.

Device replacement

If it is necessary to replace one of the devices in the topology, you can avoid the time-consuming process of reconfiguration by means of the "Device Replacement" feature.



NOTE: Only inactive devices can be replaced.



WARNING: If you are replacing a meter, it is essential to ensure that it is installed with the exact same orientation as its predecessor. This applies even in cases where the orientation was/is actually not correct and the generation/consumption registers have been exchanged via the topology configuration of the meter. The register exchange via the topology configuration only corrects the values displayed, leaving the raw data of the meter unchanged. If the new meter is installed with a different orientation from its predecessor, the raw data will have a different sign from this point onwards and all past data becomes unusable.


1 Before replacing a device, you must have applied the necessary settings on the new device, connected it to the Modbus and switched it on. This does not apply to devices connected via the digital outputs (GPIO). These devices can be replaced at any time without the "Device Replacement" feature.





To replace a device, click on "Device Replacement" 1 in the side menu. Find the entry of the device to be replaced from the "Offline devices" list 1 and click on "Edit" 1.





The entry is now expanded. Click on the drop-down menu "Choose a Device" 1 and select the new device by clicking on it. Confirm the action in the following dialogue box.

If you do not want to replace the device but to permanently delete it, do not select a replacement in the drop-down menu and instead click on the "Remove" button 1.

Warning: This action cannot be undone!

9 SETTING UP STRATEGIES AND ENERGY SERVICES

9.1 PROCEDURE

An energy services strategy is the implementation of a specific application, such as self-consumption optimisation, in a strategy for controlling actuators. The procedure for this is as follows:

- 1. Definition of actuator groups that will implement the energy service, e.g. a battery that performs self-consumption optimisation at the grid meter, or a PV installation that is not allowed to feed into the public utility grid.
- 2. Configuration of energy services, e.g. self-consumption optimisation.
- 3. Assignment of the configured energy services to actuator groups.

Using a decision tree (PRO version), several strategies can also be linked to each other and carried out dependent on conditions. This combination of applications is also known as "multi-use". Very complex scenarios can be implemented in this way. Be aware that each actuator can only ever implement one strategy at a time. The procedure for setting up a decision tree is as follows:

- 1. Definition of standard strategy
- 2. Definition of strategy links and decision paths
- 3. Activation of energy service strategies

9.7 OVERVIEW OF ENERGY SERVICES



NOTE: Only inactive devices can be replaced.

First, strategies must be defined. As part of this, an energy service (e.g. target power self-consumption) is assigned to an actuator group (e.g. Battery 1), which implements the service.

The following energy services are available for selection:

Priority-based energy services (with simplified configuration interface)

- Self-consumption
- Physical peak shaving

Expert energy services

- Target power
 - Advanced
 - Self-consumption
 - Physical peak shaving
 - PV regulation
 - Calculated
- Grid isolation
- Switch/set point
- Switchable loads/generation
- RLM peak shaving
- Forecast-based charging
- Remote control

- Off-grid generator curtailment for target SoC
- Charging station control
- Dynamic electricity tariffs

9.3 ACTUATORS AND ACTUATOR GROUPS

Actuators with a similar function (e.g. generators or batteries) can be combined to form actuator groups. There are four different types of groups:

- 1. "Simple priority" actuator group Actuator priorities for performing an energy service are determined by the order in the group. This parameterisation is suitable for easy creation of cascade connections.
- 2. "Extended priority" actuator group Actuator priorities can be freely defined and differentiated by generator and consumer.
- 3. Multi-battery actuator group Used to combine multiple batteries into a virtual battery.
- 4. "Charging station infrastructure" actuator group combines different wallboxes.




2

NOTE: The batteries are also listed individually in the actuator groups and can be used individually in strategies.

Overview of strategies

To see an overview of all existing strategies or to create a new strategy, click on "Strategies" in the side menu.




All existing strategies 1 are displayed on the opened page. You can duplicate any of the existing strategies on this page 📵. Inactive strategies can be deleted using the button 🕡. You can identify unused strategies by the marking (1), and you can create a new strategy using the button (2).


Overview of actuators and actuator groups

You can only view, manage, edit or create actuator groups by calling up or creating an expert strategy.

1 Click on (e) to create a new strategy.




Select Expert Strategy a



You will then see all actuators as well as automatically created groups if there are two or more actuators of the same type. 1 name of the expert strategy, 1 create new strategy, 1 select filter for list, d, add the actuator/actuator group.

"Simple priority" actuator group

- NOTE: There should never be more than one battery integrated in an actuator group with "simple priority".
- NOTE: If a PV installation and a battery are integrated in an actuator group with "simple priority", this battery will never be charged by the integrated PV installation.




Give the new actuator group a name in the "Name" 1 field . Next, select the "Simple priority" setting in "Parametrization" (b).




Select the actuators 1 you wish to combine in the group. The sequence indicates the priority when performing the energy service. The first actuator selected has the highest priority during generation. The actuators selected afterwards have the highest priority during consumption and charging. Then click on "Confirm". 1.

bat TesvoltPCS Tesvolt 43989.0

"Extended priority" actuator group



Give the new actuator group a name in the "Name" field (a). Next, select the "Advanced priority" setting in "Parametrization" (b).



Next, select the actuators (a) you wish to combine in the group. Any sequence is possible. Next, determine the priority of the actuators (b) when they are used to perform an energy service. Use a sign to indicate whether the actuator prefers to generate (positive sign) or charge (negative sign). The absolute value determines the level of priority compared to the other actuators (higher value = high priority). Finally, click on "Confirm" c.

2

"Multi battery" actuator group

If the TESVOLT Energy Manager detects several batteries in a system, they are automatically combined in a group. However, you can also combine just one part of the storage system in a group manually. The batteries that are combined in a group make configuration easier for you, as all batteries combined in the group are controlled collectively and you only have to configure the group, rather than each individual battery.

The combined batteries are kept at a uniform state of charge (SoC) in operation. To avoid excessive cycling during charging, the TESVOLT Energy Manager allows the individual storage systems a defined deviation from the specified (joint) SoC. This deviation can be set as the delta SoC window in % (see step (3)).

- NOTE: The batteries are also listed individually in the actuator groups and can be used individually in strategies.
- NOTE: The functions "off-grid use" and "grid replacement operation" are not available when you combine different TESVOLT storage systems into one actuator group.
- NOTE: If your system features several batteries set up in master/slave systems, these are only ever treated as an individual storage system in the TESVOLT Energy Manager. Master/slave systems can only be controlled collectively.



Give the new actuator group a name in the "Name" field 1. Next, select the "Multi-battery" setting in "Parameterisation" (b).




Then click on "Select actuator(s)..." 1 and select the battery storage system that you would like to group by clicking on the relevant option field. In the "Delta-SoC Window in %" field 1, enter the maximum deviation of the state of charge for the storage systems in the group. The tolerated deviation prevents cycling or ON/OFF oscillation during charging. Finally, click on the "Confirm" button 🚺





You can now set up additional groups for the remaining actuators if necessary. Once you have set up all the desired actuator groups, click on "Save" 1.

"Charging station infrastructure" actuator group



- Name > Give the new actuator group a name in the "Name" field.
- **b** Type > Select the power set point as the type.
- C Parametrization > Select charging station infrastructure from the drop-down menu.
- d Actuators > Select the required wallboxes from the drop-down menu.

Save your details by clicking on "Confirm" (1).

For the charging station infrastructure actuator group, you can, for example, configure the "Physical peak shaving" energy service strategy; see "Example - configuration of the TESVOLT PCS" on page

Information on control via the TESWORLD portal can be found in the section "Charging station control" on page 107.

9.4 APPLICATIONS

All applications are configured by means of energy services in the form of strategies. Each actuator can only be assigned to one strategy. This does not apply to strategies that are executed on a case-by-case basis using a decision tree.

Without a decision tree, however, even multiple applications can be run at the same time if different actuators are used. For example, you can use a battery for peak shaving or self-consumption optimisation, and at the same time limit the feed-in of a PV installation (active power limitation) and also switch generators or consumers.

General configuration of applications

Priority-based energy service strategies

With TESVOLT Energy Manager Version 3.2.0 or higher, in addition to expert strategies you can also choose from simple, preconfigured strategies: self-consumption optimisation and peak shaving.


These strategies implement their respective energy services on the basis of a list in which the controllable device classes are listed according to their priority and can be moved.



NOTE: As a priority-based energy service strategy, only physical peak shaving is possible. For load peak shaving, please use the corresponding expert strategy (see "Load peak shaving" on page 100).

The two strategies differ only in their predefined classification. The priority-based energy service "selfconsumption optimisation" is designed for greater excess power, while "peak shaving" is designed for greater power drawn from the grid. However, these requirements can be freely adapted in both strategies at a later stage.

Setting up priority-based energy service strategies



In the side menu, go to Energy Manager > Strategies and click on "Strategy+" (1)



Now select one of the two priority-based energy service strategies: "self-consumption" (a) or "peak shaving" (b). Click on "Expert strategy" (c) to configure the energy services in even greater detail and more comprehensively.

3




If you selected "Self-consumption optimisation" (for "peak shaving," continue with the next step (2)), enter a name for the energy service strategy a and specify whether the maximum feed-in to the grid in watts should be limited to a certain amount **(b)** (e.g. 70% of the installed kWp of your PV installation) or is unlimited. Click on "Create strategy" 📵 to create a corresponding strategy under the specified name. Click on "Change strategy type" (e) to return to the previous selection. Otherwise, continue with step [3]






If you selected "peak shaving," enter a name for the energy service strategy 1 and specify whether the maximum feed-in to the grid in watts should be limited to a certain amount 🕕 or is unlimited. Click on "Create strategy" 🕕 to create a corresponding strategy under the specified name. Click on "Change strategy type" (e) to return to the previous selection.





Once you have created the new strategy, a dialogue box will appear indicating that the new strategy is still unused. To activate it, click on "Activate" (a). Click on "Overview" (b) to navigate to the overview of the strategies without activating the new strategy.




If you want to activate the new strategy, click on the drop-down menu and select the entry for your chosen strategy by clicking on it. Save the activation by clicking on "Save" (b)

Editing priority-based energy service strategies



If you want to edit a priority-based energy service strategy, click on the corresponding strategy button a on the strategy overview page.




In field 1 you can limit the grid feed-in; if 1 is activated, the feed-in is unlimited. An entry in field 1 limits the possible power consumption from the utility grid. You can set the priority of the consumers d by moving the items in the list. In the sections between the range markers e, the number of the entry determines the priority, i.e. the order in which the consumers are supplied with energy: the lower the number, the higher the priority. Non-controllable consumers must have the highest priority and are always covered first. The area between the markings "Additionally supply from the battery" and "Not in use" corresponds to the area in which there is excess power, e.g. due to a PV surplus. Finally, save your settings by clicking on 1

Expert strategies

In addition to priority-based energy service strategies, there are also what are known as expert strategies. These cover all known applications, including the classic configuration of self-consumption optimisation and physical peak shaving.


Setting up expert strategies



In the side menu, go to Energy Manager > Strategies and click on "Strategy+" (a).




Then click on "Expert strategy" (



Choose a name for your new strategy and enter it in the field (a). Finally, click on "Create strategy" (b) to complete creation of the new strategy. If you would prefer to select a priority-based energy service instead, click on to return to strategy selection.


4 Now set up the desired energy service for the specific actuators. Details on the configuration of the available energy services can be found on the following pages.




Once you have configured the desired energy service, click on "Confirm" a.



You can now set up additional energy services for the remaining actuators if necessary. Once you have set up all the desired energy services for the strategy, click on "Save" (a).



In the dialogue box that appears, you will be asked whether you would like to activate the new strategy. To do this, click on "Activate" a. To go to the strategy overview page without activating it, click on "Overview" b.



To activate the strategy, select the appropriate entry from the list in the drop-down menu (a). Alternatively, you can create a multi-use strategy via button (b) (detailed instructions on the multi-use functionality can be found under "Multi-use" on page 95). Finally, save the activated strategy by clicking on "Save".

Self-consumption optimisation

Energy service: "self-consumption optimisation" priority-based energy service or "target power" expert strategy with "self-consumption" preselection

Target power: 0 kW


Position in topology: Grid connection point

Actuator group: Battery used.


Description: The battery tries to reduce the amount drawn from the grid to 0 by discharging, and

charges in the case of excess power.


- 1 Configure a priority-based "self-consumption optimisation" energy service according to the procedure described under "Setting up priority-based energy service strategies" on page 70
- 2 Alternatively, you can create a new expert strategy as described in steps [1] - [3] under "Setting up expert strategies" on page 73. Enter a new name for the strategy (e.g. "self-consumption") and then confirm your entry by clicking on the [+] symbol.



Add the desired actuators. You can also create a new actuator group by clicking on "New actuator group +" b or filter the existing entries by clicking on "Filter by actuators..." c. Now add an actuator or actuator group to the new energy service by clicking on the "Add+" button 1 for the relevant entry (for self-consumption optimisation, select a storage system).



Under "Actuator groups" you can see the same number of "Battery" sections as there are logical units of this type. If you want all batteries to behave the same way, use the actuator group (see "9.3 Actuators and actuator groups" on page 66); otherwise, select the entry for the desired battery and click on the drop-down menu "Select an Energy Service" 📵 on the right-hand side. Select "Target power" from the list.



In the "Target power – Self-consumption" dialogue box a, the "Target Power in W" b is preset to "0". Next to "Position in Topology" you will see a switch icon (). The "Grid" setting is always preset to ON. This means that the values from the grid meter are used for control. Finally, click on "Confirm" $oldsymbol{d}$.



You can now set up additional energy services for the remaining actuators if necessary. Once you have set up all the desired energy services for the strategy, click on "Save" a

7 Activate the strategy or add it to a multi-use strategy. To do this, proceed as described in step 8 under "Setting up expert strategies" on page 73 f.


Physical peak shaving

Energiedienstleistung: peak shaving" priority-based energy service "or "target power" expert strategy with "physical peak shaving" preselection


Actuator group: Battery

Description: The value of the target power must be positive and determines the maximum output drawn from the utility grid. If this value is exceeded, the storage system discharges to cap the load peak. The battery charges up to the specified target power from any available source, which can include from the utility grid.


- Configure a priority-based "physical peak shaving" energy service according to the procedure described under "Setting up priority-based energy service strategies" on page 70
- Alternatively, you can create a new expert strategy as described in steps 1 3 under "Setting up 2 expert strategies" on page 73. Enter a new name for the strategy (e.g. "physical peak shaving") and then confirm your entry by clicking on the [+] symbol.



Under "Actuator groups" you can see the same number of "Battery" sections as there are logical units of this type. If you want all batteries to behave the same way, use an actuator group (see "9.3 Actuators and actuator groups" on page 65); otherwise, select the entry for the desired battery and click on the drop-down menu "Select an Energy Service" 1 on the right-hand side. Select "Target power" from the list.



In the "Target-power" dialogue box, select the "Physical Peakshaving" preselection (a). Then, for the "Target Power in W" 🕠, enter the desired value for the power limit, e.g. 80000 for 80 kW. Next to "Position in Topology" you will see a switch icon 🕻. The "Grid" setting is preset to ON. This means that the values from the grid meter are used for regulation. If you want the peak shaving to take place in a different position in the topology, first click on the "Grid" switch and then select the appropriate meter from the drop-down menu. Then, click on "Confirm" 🚺 to apply the settings.



You can now set up additional energy services for the remaining actuators if necessary. Once you have set up all the desired energy services for the strategy, click on "Save" (a).

6 Activate the strategy or add it to a multi-use strategy. To do this, proceed as described in step [8] under "Setting up expert strategies" on page 73 f.


Grid isolation - battery discharge protection mode

Energy service: "Grid isolation - battery discharge protection mode"


Actuator group: Battery

Description: To prevent the battery discharging too deeply, the system is switched off after a set time in battery discharge protection mode. The system is switched on at periodic intervals to recharge the uninterruptible power supply (UPS).

1 Create a new expert strategy as described in steps 1 - 3 under "Setting up expert strategies" on page 73. Enter a new name for the strategy (e.g. "Battery discharge protection mode") and then confirm your entry by clicking on the [+] symbol.



Under "Actuator groups", you can see the same number of "Battery" sections as there are logical units of this type. If you want all batteries to behave the same way, combine them into an actuator group (see "9.3 Actuators and actuator groups" on page 65). Otherwise, find the entry of the battery you want and in the right-hand column next to the entry, click on the drop-down menu "Select energy service" 1. Select "Grid isolation – battery discharge protection mode" from the list.



- 3 SoC limit > Define the SoC limit using the slider.
- (greater than 0) that the system should be switched on for to charge the uninterruptible power supply (UPS).
- c OFF time > Enter the time in minutes (greater than 0) that the system remains switched off for. Confirm your entries by clicking on "Confirm" 1.



You can now set up additional energy services for the remaining actuators if necessary. Once you have set up all the desired energy services for the strategy, click on "Save" (a)

[5] Activate the strategy or add it to a multi-use strategy. To do this, proceed as described in step [8] under "Setting up expert strategies" on page 73 f.


Switch/set point

Energy service: "Switch/set point" (expert strategy)


Actuator group: Battery

Description: For switching the on/off switch on the TESVOLT Energy Manager and for defining a set point (the set point must only be configured in expert mode by administrators)

Create a new expert strategy as described in steps 1 - 3 under "Setting up expert strategies" on 1 page 73. Enter a new name for the strategy (e.g. "Battery discharge protection mode") and then confirm your entry by clicking on the [+] symbol.



Under "Actuator groups" you can see the same number of "Battery" sections as there are logical units of this type. If you want all batteries to behave the same way, use an actuator group (see "9.3 Actuators and actuator groups" on page 66); otherwise, select the entry for the desired battery and click on the drop-down menu "Select an Energy Service" (a) on the right-hand side. Select "Switch/set point" from the list.



- Set the unit's switch by activating the green box by clicking on "On" or by deactivating "Off".
- b Confirm your entries.





You can now set up additional energy services for the remaining actuators if necessary. Once you have set up all the desired energy services for the strategy, click on "Save" (a).

[5] Activate the strategy or add it to a multi-use strategy. To do this, proceed as described in step [8] under "Setting up expert strategies" on page 73 f.

PV installation active power limitation

Energy service: "Target power", "PV curtailment" preselection

Target power: Freely selectable output at the grid connection point (negative value)

Actuator group: PV

Description: The specified target power must be negative and defines the maximum power fed in to the public utility grid. If this value is exceeded, the output of the PV installation is reduced in order to limit the feed-in to the specified value.

Create a new expert strategy as described in steps (1) – (3) under "Setting up expert strategies" on page 73. Enter a new name for the strategy (e.g. "PV installation active power limitation") and then confirm your entry by clicking on the [+] symbol.



Under "Actuator-Groups", find the section "PV". If there is more than one PV installation in the system, these are called "PV 1", "PV 2", etc. (PV installations cannot be combined into groups). In the right-hand column under the heading "Energy Service", click on the drop-down menu "Select an Energy Service" for the actuator group "PV 1" 📵 and select "Target-power".



In the "Target-power" dialogue box, select "PV-Curtailment" from the drop-down menu 1, and for the "Target Power in W" 🕦 enter, for example, "-7000", which corresponds to a feed-in of 7 kW (70% of a 10 kWp PV installation). Next to "Position in Topology" you will see a switch icon. The "Grid" setting is preset to ON. This means that the values from the grid meter are applicable for regulation. Then, click on "Confirm". If you have several PV inverters to configure in your system, repeat the process from step 2 for each additional PV inverter.





You can now set up additional energy services for the remaining actuators if necessary. Once you have set up all the desired energy services for the strategy, click on "Save" (a)

[5]

Activate the strategy or add it to a multi-use strategy. To do this, proceed as described in step [8] under "Setting up expert strategies" on page 73 f.

PV installation active power limitation zero feed-in


Energy service: "Target power", "PV curtailment" preselection


Target power: 0 Actuator group: PV

Description: The specified target power must be 0 and prevents the PV installation feeding into the utility grid. If the power falls below this value (which means the PV installation is feeding in), the output of the PV installation is reduced to the point that feed-in stops.



NOTE: In order to meet the normative guidelines for zero feed-in in Germany, you must be able to limit the SoC of the battery storage system using a decision tree so that it can absorb surplus production at any time, meaning it can reliably prevent feed-in.





Under "Actuator-Groups", find the section "PV". If there is more than one PV installation in the system, these are called "PV 1", "PV 2", etc. (PV installations cannot be combined into groups). In the right-hand column under the heading "Energy Service", click on the drop-down menu "Select an Energy Service" for the actuator group "PV" a and select "Target-power".



In the "Target-power" dialogue box, select "PV-Curtailment" from the drop-down menu 1, and for the "Target Power in W" 🕕 enter, for example, "0", which corresponds to a feed-in of 0 kW. Next to "Position in Topology" you will see a switch icon. The "Grid" setting is preset to ON. This means that the values from the grid meter are applicable for regulation. Then, click on "Confirm". If you have several PV inverters to configure in your system, repeat the process from step (2) for each additional PV inverter.



You can now set up additional energy services for the remaining actuators if necessary. Once you have set up all the desired energy services for the strategy, click on "Save" (a).

5 Activate the strategy or add it to a multi-use strategy. To do this, proceed as described in step 8 under "Setting up expert strategies" on page 73 f.

3

Generation control during utility grid operation


Energy service: "Interruptible loads/yields"

Upper/lower threshold: Freely selectable output at any point (negative/positive value)


Actuator group: Switchable generator

Description: If the power exceeds the upper threshold, a switchable generator is switched on. If the power falls to a value below the lower threshold, the generator is switched off again.


Create a new expert strategy as described in steps (1) – (3) under "Setting up expert strategies" on 1 page 73. Enter a new name for the strategy (e.g. "Generation control during utility grid operation") and then confirm your entry by clicking on the [+] symbol.



Under "Actuator-Groups", find the section "CHP" (it must be a switchable generator). If the device cannot be controlled via Modbus, then configure one of the digital outputs for it (see also "Digital outputs (GPIO) configuration" on page 47). In the right-hand column under the heading "Energy Service", click on the drop-down menu "Select an Energy Service" for the actuator group "CHP" (1) and select "Interruptible loads/yields".



In the "Upper threshold" field a enter the power value above which the generator should be switched on. In the "Lower threshold" field 📵 enter the power value below which the generator should be switched off again. The difference should equate to at least the output of the generator (ideally make it a bit larger to avoid on-off oscillation). The switch "Digital switch-state above upper threshold" 🚺 must be set to "On" for switchable generators (factory setting). As an additional measure against on-off oscillation, you can specify a start-up delay for the generator in the field "Tolerance time-window in s" The threshold must then be exceeded for the specified time before the switch-on process is activated. In the "Position in Topology" field, enter where the specified threshold should be measured. If this is not at the grid meter, deactivate the "Grid" switch 😢 by clicking on it and then select the desired measuring point from the drop-down menu. Next, click on "Confirm".



You can now set up additional energy services for the remaining actuators if necessary. Once you have set up all the desired energy services for the strategy, click on "Save" 1

[5] Activate the strategy or add it to a multi-use strategy. To do this, proceed as described in step (8) under "Setting up expert strategies" on page 73 f.

Load control


Energy service: "Interruptible loads/yields"

Upper/lower threshold: Freely selectable output at any point (negative/positive value)


Actuator group: switchable consumer (via GPIO)

Description: If the power exceeds the upper threshold, a consumer is switched off. If the power falls to a value below the lower threshold, the consumer is switched on again. The difference between the upper and lower threshold should equate to at least the power drawn by the consumer (ideally make it a bit larger) to avoid on-off oscillation. A start-up delay can also be employed.

- Configure one of the digital outputs for switching the load (see "Digital outputs (GPIO) configuration" on page 47 et seq.) and call this "Load_1".
- Now access the page "Topology" via the side menu under "Device Settings". Scroll down to the "Device Assignment" section and click on the entry "Load_1". Click on the drop-down menu "No device" and select either a dedicated meter to measure "Load_1" or, if there is no dedicated meter, select "User_1", as long as Load_1 is recorded by the grid meter. Finally, click on "Save Topology".
- [3] Create a new expert strategy as described in steps 1 - 3 under "Setting up expert strategies" on page 73. Enter a new name for the strategy (e.g. "Load control") and then confirm your entry by clicking on the [+] symbol.



Under "Actuator-Groups", find the section "Input/Output". In the right-hand column under the heading "Energy Service", click on the drop-down menu "Select an Energy Service" for the actuator group "Input/Output" (1) and select "Interruptible loads/yields".



In the "Upper threshold" field 1 enter the power value above which the consumer should be switched off. In the "Lower threshold" field 🚺 enter the power value below which the consumer should be switched on again. The difference should equate to at least the power drawn by the consumer (ideally make it a bit larger to avoid on-off oscillation). The switch "Digital switch-state above upper threshold" nust be set to "Off" for switchable consumers. As an additional measure against on-off oscillation, you can specify a start-up delay for the consumer in the field "Tolerance time-window in s" d. The threshold must then be exceeded for the specified time before the switch-off process is activated. In the "Position in Topology" field, enter where the specified threshold should be measured. If this is not at the grid meter, deactivate the "Grid" switch 😉 by clicking on it and then select the desired measuring point from the drop-down menu. Next, click on "Confirm".



You can now set up additional energy services for the remaining actuators if necessary. Once you have set up all the desired energy services for the strategy, click on "Save" (a)

[7] Activate the strategy or add it to a multi-use strategy. To do this, proceed as described in step [8] under "Setting up expert strategies" on page 73 f.

Charging station infrastructure

The charging station infrastructure (CSI) is a specific actuator group that consists exclusively of charging points. The technician uses their parameters to define how electricity is distributed to the charging points.

Actuator groups for energy services are assigned in "Strategies". You can create multiple CSI actuator groups. However, only one CSI can be active within a strategy, i.e. assigned to an energy service. You can select different distribution parameters using different strategies. The active strategy is defined by the decision tree.

The CSI only controls the current levels of the charging points, not the charging power. The charging power can differ significantly between two charging points with the same assigned current.

Parameters:

- Name: You are free to choose an actuator group name, as long as it is not already being used by another actuator group. If multiple charging infrastructures are in use, they are distinguished by this name.
- Type/parametrization: Select Power set point as the type. Then for parametrization, Charging infrastructure.
- Total limits: In this section, define the limits that the charging infrastructure as a whole must adhere
 - Please note that there will be a slight delay in charging points/cars implementing new requirements. The EMS only generates new specifications for the charging infrastructure every 20 seconds. If no command has been sent within the last 20 seconds, the last command received will be executed.
- Maximum current on the utility grid: Specifies the maximum permissible current at the grid connection point. This means that the charging infrastructure also adapts to the consumption of other units. This value refers to each individual phase, not its sum. If you do not wish to set a limit, e.g. because the charging infrastructure cannot reach the limit, you can set the limit to unlimited.
- Maximum current for the charging infrastructure: Specifies the maximum electricity drawn by the charging infrastructure. Unlike the maximum current on the utility grid, this limit does not consider other units.
- Electricity limits for charging points: In this section, set the maximum permitted current for each charging point separately.
- Charging points: Enter the charging points to be controlled by the charging infrastructure. The sequence also defines the sequence of settings on myTESWORLD. You can only select charging points that have been assigned to a unit in the *Topology* section. If charging points are not displayed, check the settings in the Topology section and adjust as necessary.

Setting up the charging station infrastructure on myTESWORLD

The charging infrastructure actuator group is configured on myTESWORLD under "Settings ightarrow Charging infrastructure".

If there is only one charging infrastructure set up for the EMS, this is selected automatically.


If multiple charging infrastructures have been set up for the EMS, first select the one you wish to configure. Here the names defined in the actuator groups are used.

For each charging point, the wallbox assigned to it in the topology and the unit name are displayed.


Ripple control receiver

Network operators can use ripple control receivers to transmit information to their customers such as limits for the grid feed-in of large photovoltaic installations. This is often a requirement for registering large-scale generation plants. The ripple control receivers pick up the radio signals from the utility grid operator. These signals are encoded on four contacts connected to the TESVOLT Energy Manager. The set limits can be entered in the UI of the TESVOLT Energy Manager and then implemented in energy services and strategies.


The four contacts of the ripple control receiver are connected to four inputs of the TESVOLT Energy Manager.



To add a ripple control receiver in the TESVOLT Energy Manager open the [Device Configuration > External Settings] page and click on "Configure External Settings".




Now click on "Select a model" and select the entry "Ripple Control Receiver (RRCR) RippleControl" from the drop-down menu.




Configure the available settings: In the 📵 field, enter a name and under connections 1 to 4 🕩 select the matching wired inputs of the Energy Manager. The numbers 1 to 4 correspond to the outputs of the ripple control receiver.




NOTE: Please note that the assigned name cannot be changed later.



Please enter the corresponding generation limits in watts for the connection combinations (4 bits = 16 combinations) below the connection assignment. If you only want to use the four default settings, click the [+] button three times to configure three additional switching combinations and activate only one contact A1 to A4 for each. The generation limits 1 are assigned to the contacts 1 in the next step. Now enter the corresponding power setting points for these switching combinations. Save these settings by clicking [Save].



You can then use these feed-in limits in an energy service strategy by assigning the energy service "Marketer Interface/Ripple Control Receiver" to the corresponding actuator group.




Then, determine the position in the topology that the restrictions should affect. "Utility grid" should normally be selected here.


Marketer interface

The marketer interface is used to set up a marketer to carry out energy trading or PV direct marketing with the TESVOLT Energy Manager. The Energy Manager adheres to these external specifications and implements them in accordance with the marketer's specifications.

If you would like to use the marketer interface, it must first be set up as described under "Configure external specification" on page 54



Create a new expert strategy (as described under "Setting up expert strategies" on page 73) or open an expert strategy that you would like to customise. Select the relevant PV or battery actuator group and select "Marketer interface" as the energy service.



In the dialogue box that appears, click on "Confirm". The strategy can then be activated or used as part of a decision tree.

Control using GPIO inputs


Once you have completed the configuration of the input according to section "Digital input (GPIO) configurations" on page 49 and the input is shown as "Online" in the overview on the GPIO page, it is available as a sensor under "Simple Sensors". You can now evaluate it in decision trees and use it to control switching and setting points, for example. Here is an example of a decision question in a decision tree:





Select "Time switch on?" as the decision question and click "Edit". Select "Simple Sensors" in the upper field and the input in the lower field, e.g.: "Input_Signal_io_0_SwitchInput". If this contact is now closed, the decision leads to the YES path. If the contact is open, the decision leads to the NO path of the other tree.

Multi-use



Multi-use enables you to execute different strategies on a case-dependent basis. To achieve this, decision nodes are set up in a decision tree 📵, at which point certain conditions are checked and one of two strategies 🕦 is activated. In place of the strategies, additional decision nodes 🕡 can also be configured with new conditions. Options that can be selected as conditions:

- 1. SoC > ... %?
- 2. Time switch on?
- 3. Value hysteresis
- 4. Network status? (Grid operation, off-grid operation, error, grid isolation process, grid connection process, etc.)
- 5. "No" path can't be evaluated
- 6. Marketer specification

If you wish to make changes to the decision node or one of the strategies in the decision tree, click on the button f next to the node or the relevant strategy.

In addition, you must define a default strategy 1 that will be used if problems arise during the evaluation of the decision tree. Once a strategy has been fully created, it must be saved by clicking on "Save"


By clicking on the button g, you can configure additional options for the decision node.




In the drop-down menu 1, you can define a time hysteresis for evaluating the node question. You can set the hysteresis in seconds using the small arrow buttons in the area (b). Then confirm the desired value by clicking on the "+" button (

In the drop-down menu (1), you can select a fallback strategy that will be executed if the decision tree cannot be evaluated. The following options are available:


- 1. The last valid decision,
- 2. the default strategy,
- 3. ... all other strategies created.



In order to configure the decision tree, first you must set up all the strategies that will be used (as described in the section "Expert strategies" on page 73, steps (1) to (3). Then, click on "Save" (3).




First, select the default strategy $oldsymbol{a}$. Then click on "Initialize the decision-tree" $oldsymbol{b}$.




Once the page has automatically refreshed, you will see the unconfigured decision tree. Now start setting up the first decision node by clicking on the drop-down menu "Choose a decision-question" 1.



In this example, the condition to be checked is whether the SoC is more than 90%. To set this up you must adjust the slider next to "SoC Threshold in %" 📵 to a value of 90 %. "SoC deadzone in %" 🕕 defines by how much the threshold must be exceeded after a switching process, before another switching process can take place. This aims to prevent ON-OFF oscillation. Then, under "Physical Device" 📵 select the device that the settings should refer to.




Now select the strategy that should be carried out if the answer to the question in the first decision node is "Yes". To do this, click on the drop-down menu 📵 on the left side of the decision node and select the planned strategy. Now configure the right side ("No") of the decision node 🕦 with the alternative strategy and then click on "next" (c).




On the next page you can see an overview of the configured energy services. First, the strategies used in the decision tree are listed 1. You can expand these by clicking on "Activation Rules" 1. Finally, click on "Save" c. The decision tree is saved and activated.

Time of Use


The Time of Use application enables time-dependent generation and load control in grid operation. The function is based on time series profiles, in which switching points are temporally defined. The time series profiles can then be evaluated in decision trees and linked with the desired actuators. A distinction is made between "generic" and "time switch" time switch profiles. A "time switch" time switch profile can only contain "On/Off" values. As with a time switch, this enables actuators to be switched on and off at specific times. Generic time series profiles can contain any positive or negative numerical values. These values can be sent to the relevant actuators at the specific times.




In the side menu under "Energy Manager", click on "Time Series Profiles". In the field "Name" 1 enter a name for the time series profile you are creating. Then click on "Create empty profile".




The page will refresh with several additional sections. You now need to configure the time series profile on the right side. Click on the switch next to "Type" 📵 to select the setting "time switch". "Time switch" only recognises the states "On" and "Off".



Now specify the periodicity 📵, i.e. what time span the time series profile covers (before it repeats). If you leave the setting on "Off", you can select any time in the future. In this case, the switching process is only carried out once and not repeated. For our example, we select a periodicity of a day.




In the next step, in the "Edit time series" section, define the switching times/states. For "Time Switch (On/Off)" (a) select the desired switch state, and for "Time" (b) set the time for the first switching process by adjusting the slider or using the arrow keys on your keyboard. Then click on "Add" 🚺 You can now see the new entry for the switching process in the "Profile Overview" list 🕕. Finally, under the heading "Save time series profile" click on "Save" (2). The profile status in the section "Time Series Profile Selection" should now have changed to "saved".



If you would like to create a generic time profile, begin as described in step $\begin{pmatrix} 1 \end{pmatrix}$ (if necessary select a new name). In the configuration of the time series profile, set the type 📵 to "generic". Under "Periodicity" (b) select the desired option if applicable or select "Off" to set a time in the future at which the value 🕠 should be sent to the actuator. Then click on "Add" 🕕. You can now see the new entry for the switching process in the "Profile Overview" list 📵. Finally, under the heading "Save time series profile" click on "Save" (1). The status (3) of the profile in the section "Time Series Profile Selection" should now have changed to "saved".

 $\left[6 \right]$




You can now control actuators that are dependent on the time series profile created in a decision tree. Proceed as described in the section "Multi-use" on page 94) to set up a decision tree. In a decision node, click on the drop-down menu "Choose a decision-question" and select "Time switch on?". You will now see the dialogue box "Parameterisation of the time switch". In the drop-down menu "Time series selection" (a) select the desired time series profile by clicking on it and then click on "Confirm" (b). Then continue with the configuration of the decision tree.

Load peak shaving

The "Load peak shaving" function optimises the behaviour of the connected battery storage system on the grid connection point. Unlike physical peak shaving, a freely selectable time period is considered here during which the average drawn output from the public utility grid may not exceed a specific value. In Germany, the interval for load peak shaving is 15 minutes.


NOTE: If the peak shaving fails, i.e. the specified maximum value for the amount drawn from the grid is exceeded, the peak demand reached in this case is automatically set as the new maximum power value. If necessary, you can manually reset this value via the load peaks configuration and the function "Schedule Peak Power thresholds" at any time in the future, or via "Current Peak Power and Interval".



First, configure the global settings for load peak shaving. In the side menu, click on "Energy Manager" \rightarrow "Load-Peaks". In the field "Peak Power in W" $\stackrel{ ext{\scriptsize (1)}}{ ext{\scriptsize (2)}}$ enter the value for the power limit. To confirm the value, click on "Override" 🕦 The interval is preset at 15 minutes. If you would like to specify a different interval, click on the "Edit Interval" switch 🚺 and enter a new interval in the field "Interval in min". In the section "Schedule Peak Power thresholds" you have the option to activate a new peak power at a specified time. To do this, enter the new peak power in the field "Peak Power in W" (1) Next, set the activation time. As soon as you move the mouse pointer over the "Activation Time" field (2), a small calendar display appears, where you can enter a date and time. To apply the changes, click on "Add" 1. In the section "Former and scheduled Peak Power thresholds", you can now see a grey entry 💡 with the current peak power limit and an entry recorded in green (h) with the date you have scheduled. If the details are correct, then click on "Save" 1.

Create a new expert strategy as described in steps (1) - (3) under "Setting up expert strategies" on 2 page 73. Enter a new name for the strategy (e.g. "Load control") and then confirm your entry by clicking on the [+] symbol.





Then, on the "Strategies" page, select the item "Load-peakshaving" for the actuator group "Battery" in the drop-down menu "Select an Energy Service". In the "Load-peakshaving" dialogue box, for the field "Interval in min" 📵 you can enter the length of the interval over which the average value of the peak load should be calculated.

For "Peak Power in W" 🕦 enter the value for the maximum power drawn (e.g. 80000 for 80 kW). You have already specified both values previously in step 1. If you adjust the values, they will be changed across the system. For "Safety margin in W" 🕻 you can define a safety margin, which should prevent the threshold being unintentionally exceeded. Then, click on "Confirm" d. If you have several batteries in your system that are not configured as a group, repeat this step for each additional battery as needed.





You can now set up additional energy services for the remaining actuators if necessary. Once you have set up all the desired energy services for the strategy, click on "Save" a.



Activate the strategy or add it to a multi-use strategy. To do this, proceed as described in step [8] under "Setting up expert strategies" on page 73 f.

Back-up power (Multi-use with peak shaving)

In a power outage, a battery inverter supplies the grid independently, without the TESVOLT Energy Manager having to step in. For the "Back-up power" application, therefore, strategies are required that ensure that the storage system has sufficient energy available in the case of back-up power being needed, and that additional applications can still be employed where applicable. As requirements and topologies vary widely, only the basic procedure is explained here using an example.

Energy service: "Multi-use" with the applications peak shaving and back-up power

Strategy 1-1: Load peak shaving with actuator group battery

Position in topology: Grid connection point

Strategy 1-2: Target power advanced with actuator group battery


Position in topology: Battery

Strategy 2: Grid isolation with actuator group battery


Description: The first decision node checks whether there is grid operation. If "Yes": next decision node; if "No": grid isolation.

The second decision node checks whether the SoC is over 50%. If "Yes": load peak shaving is carried out; if "No" the battery is charged with 1 W (setting for dead zone 50%: the battery cannot be discharged as this is only possible if both strategies demand it – which is not possible due to Strategy 1. Following discharge through grid isolation, charging of the battery storage system resumes when there is grid operation again, taking into account the max. load power limit).


- First, configure the global settings for load peak shaving as described in the previous section "Load peak shaving" on page 100.
- Set up a new "Load peak shaving" strategy (Strategy 1-1) (as described, for example, in the section "Setting up expert strategies" on page 73, steps (1) to (3). For the actuator group Battery 1, select "Load peak shaving" as the energy service and configure the function.
- 3 Set up a new "1 Watt battery charging" strategy (Strategy 1-2). For the actuator group Battery 1, select "Target-power/advanced" as the energy service. Set the target power to 1 W, and the position in the topology as "Battery".
- 4 Set up a new "Grid isolation" strategy (Strategy 2). Select Battery 1 for the actuator group, and "Grid isolation" as the energy service.
- 5 Scroll to the bottom of the page and click on "next".



On the newly loaded page, first select your default strategy (a). This is used if problems occur with evaluation in the decision tree. Then click on "Initialize the decision-tree" 1.




First select the question for the first decision node 1. In back-up power applications, the question about the grid state is normally at the start. Select the "on-grid" state as the parameter. If the system is in grid operation, this question is answered with "Yes"; in grid isolation, with "No".




Now, on the left, "Yes" side, click on "Convert to Decision" 1

7


9




When the strategy has been converted into a decision node, select as the decision question "SoC > ...?". In the dialogue box that opens for setting the parameters, select for "SoC Threshold in %": 50% 1; for "SoC deadzone in %": 50 % 🕩; for "Physical Device" 酦: Battery 1. Finally, click on "Confirm" 🕕



Now select the strategy for the left, "Yes" side $\frac{1}{2}$ of the second decision node. Here you select the strategy that is to be used if the SoC is $\frac{50-100}{6}$. So select "Load peak shaving".




Now select the strategy for the right, "No" side \bigcirc of the second decision node. Here you select the strategy that is to be used if the SoC is 0–50%. Select "1 W battery charging" here.



Finally, select the strategy for the right, "No" side of the first decision node. Here you select the strategy that is to be used if there is no grid operation. Select the strategy "Grid isolation" here and finally click on "next" b.

[13]




You come to the page "Energy Service Configurations Summary". Here you can see three demarcated sections with the existing strategy configurations. Click on "Activation Rules" (a), and these are also displayed. Finally, click on "Save" b.

Forecast-based charging

To maximise self-consumption while simultaneously minimising feed-in peaks, battery capacity is maintained according to the weather forecast in order to avoid feed-in and/or curtailment of the PV installation (e.g. 70% regulation). The TESVOLT Energy Manager automatically controls the charging and discharging of the battery such that curtailment of the PV installation is kept to a minimum. The Energy Manager has a smart way of doing this, namely by determining the forecast PV output from local meteorological data. The Energy Manager therefore always knows how much energy is available at what point in time

- 1. Create a new expert strategy as described in steps 1 - 3 under "Setting up expert strategies" on page 73. Enter a new name for the strategy (e.g. "Load control") and then confirm your entry by clicking on the [+] symbol.
- 2 Now, in the side menu go to "Energy Manager" → "Energy Services". Add the actuator group "Battery" to the strategy. Click on the drop-down menu "Select an Energy Service" and select "Forecast-based Charging".




In the "Forecast-based Charging" dialogue box, enter the capacity of the battery in the field "Capacity in kWh" (a). Then click on "Confirm" (b). If you have several batteries to configure in your system, you can group them beforehand, or repeat the process from step [2] for each additional battery.

- 4 Finally, click on "next". You now come to the "Energy Service Activation" page. Here, select a default strategy and/or create a decision tree with the new strategy (see also the section "Back-up power (Multi-use with peak shaving)" on page 102, which describes a multi-use application with load peak shaving), or click again on "next". On the following page, "Energy Services Configurations Summary", scroll all the way down to the very bottom of the page and click on the "Save" button.
- **NOTE**: Please note that the energy service strategy **forecast-based charging** must be approved by TESVOLT Support.

Charging station control


During operation, a wide range of settings can be adjusted by the user.




Off-grid generator curtailment for target SoC

The energy service off-grid generator curtailment enables generator systems to be curtailed off-grid. The energy management system ensures that the maximum charging capacity of the generator's battery is never exceeded. The generator installation (e.g. photovoltaic installation) complies with the battery's maximum SoC limit and keeps battery discharge and charge to a minimum.

- NOTE: Please note that, for the energy service strategy off-grid generator curtailment for target SoC, you must select a generator.
- Create a new expert strategy as described in steps (1) (3) under "Setting up expert strategies" on page 73. Enter a new name for the strategy (e.g. "Load control") and then confirm your entry by clicking on the [+] symbol.
- Now go to "Energy Manager" → "Energy Services" in the side menu. Add the actuator group "PV 1" to the strategy. Click on the drop-down menu "Select energy service" and select "Off-grid generator curtailment for target SoC".



In the dialogue box "Off-grid generator curtailment for target SoC" 1, select the desired battery in the drop-down menu next to "Grid provision battery". Then click on "Confirm" 🕕.



Or activate the expert mode $oldsymbol{0}$ by ticking the box in the dialogue window "Off-grid generator curtailment for target SoC". Select a battery in the drop-down menu under "Grid provision battery" 🕛. Use the slider to set the maximum state of charge \bigcirc . Then click on "Confirm" \bigcirc .

[5] On the overview page of the new energy service strategy, click on "Next" (at the bottom). This takes you to the "Energy Services Activation" page.



You can now set up additional energy services for the remaining actuators if necessary. Once you have set up all the desired energy services for the strategy, click on "Save" 1.

[7] Activate the strategy or add it to a multi-use strategy. To do this, proceed as described in step (8) under "Setting up expert strategies" on page 73 f.

Dynamic electricity tariffs

There are a number of ways you can use the TESVOLT Energy Manager dynamic electricity tariffs:

Energy cost provider: you can store your access data for the providers aWATTar and Tibber in the configuration so that the TESVOLT Energy Manager can retrieve and process this data.

Classification into high/medium/low: the TESVOLT Energy Manager automatically classifies the electricity prices it receives into three categories: high, medium and low. You can use this classification in the time series format as a basis for various strategies, energy services and decisions.

Electricity price-based switching: you can also switch consumers on or off based on fixed, individually defined electricity price limits. It is also possible to set the desired power consumption depending on the price level.

Electricity price-based wall box control: you can charge electric vehicles automatically at the optimum cost based on electricity price fluctuations. Simply enter the desired amount of energy in kWh and the desired departure time.


Energy cost provider

Time Series Profiles

The linkage of dynamic data from energy cost providers (e.g. Tibber, aWATTar) allows this data to be used by the TESVOLT Energy Manager e.g. for price-based switching of generators, charging of electric cars or calculations of energy services or in decision trees.


To configure a provider for dynamic electricity prices, please proceed as follows:

Click on the "Energy Cost Provider" entry in the menu on the side.




Clicking on 🔞 "Set up new energy cost provider" will take you to the selection page of energy cost providers that are currently available.





Now click on "Select a model" and select the desired provider from the drop-down field with a mouse click. Please provide any additional information that may be required.





NOTE: The Energy Manager must be able to access the Internet in order to set up an energy provider.




WARNING: Only one energy cost provider should be configured to ensure consistency of the electricity price data used.

Price classification

In order to respond to the options provided through dynamic electricity pricing, the Energy Manager records the data from the configured provider and automatically classifies it into three categories: high, medium and low. The classification is applied to the prices received on a daily basis:

- The electricity price is considered "high" when it is in the upper third for the day
- It is considered "low" when in the lower third
- Otherwise it is considered to be "medium"

These categories are then made available to you in the form of time series profiles, with the option of having them evaluated accordingly by the TESVOLT Energy Manager:




The time series profile "electricity_price" contains the entire list of dynamic electricity prices received. The "high_price" profile shows the periods in which a high price is to be expected, the "medium_price" profile shows those with medium prices and the "low_price" profile those with low prices.



1

NOTE: Please note that these profiles are created in such a way that the price shown is valid up to the specified hour.




In this example, the time series profile "low_price" indicates that low prices still apply until 6 pm Central European Summer Time (the value is "On"). However, prices starting at 6:01 pm are no longer considered low (the value is "Off" until midnight). This classification continues until 12:01 am, because low prices apply again from then until 1:00 am (the value is "On").

Electricity price-based switching


With the "Electricity price-based switching" function, devices can be switched on or off when a certain electricity price is exceeded or not reached, or can be operated at a certain power setting point.

A distinction is made here based on the type of actuator group:

- Switch setting point actuator group (e.g. heat pumps with SGReady connection)
- Power setting point actuator group (e.g. PV inverter)




Create a new strategy in the energy services area (e.g. "electricity_price_switching"). First, click on the "Add" button for the actuator group that will execute the strategy and then on "Select energy service" (1).



Select "Price-based switching" from the drop-down menu.

NOTE: This energy service can only be selected if (variable) electricity prices are also activated.


Electricity price-based switching of switch setting point actuator groups



You can set the switching threshold in ct/kWh in the "Price limit" 1 input field. When you configure the settings for the switch behaviour, 10 you can determine the direction in which the price limit should apply when activating the switch.

Electricity price-based switching of power set point actuator groups





Enter the switching threshold in ct/kWh in the "Price limit" 1 input field. In the "Set point (less than)", b input field you can define the set point for the actuator group when the price is below the set price limit. This means that the specified power value is sent to the corresponding actuator group as a default setting as long as the price is less than the set price limit.

This means the "Set point (greater than or equal to)" (a) defines the set point for the actuator group. when the price is equal to or greater than the set price limit.




NOTE: If the energy service strategy cannot be evaluated, then no set point is transmitted to the actuator group. Reasons for a failed evaluation may be missing price information from the energy cost provider or a prolonged loss of connection between the TESVOLT Energy Manager and the internet.


Cost-optimised charging

With price-based charging, you can tell the TESVOLT Energy Manager at what price you want to charge your electric car, when you want charging to be completed, and how much energy you want to charge during this time. For this purpose, the corresponding wall box is assigned an energy service called "Cost-optimised charging". Further settings can be made on the myTESWORLDportal.

To enable electricity price-based charging, please proceed as follows:




Open energy service strategy settings and select the energy service "Cost-optimised charging" for a wall box.



You can now specify the maximum charging power in watts for this energy service in the settings. Checking the box "unlimited" removes this limitation. The charging power is then limited by the charging point and the electric car.

3



As soon as an energy service "Cost-optimised charging" is available, you can make the dynamic settings in the myTESWORLD portal under [Settings > Electric car]. Select the appropriate actuator group first if there is more than one actuator group with cost-optimised charging.

- 4 You will then have the following input options:
 - Mode
 - Desired amount of energy in kWh
 - Planned departure time

For mode, you can choose from the following predefined options:

- Optimum cost: the vehicle is charged when the electricity price is low.
- One-time fast charging: one time full charge as quickly as possible, regardless of the price.
- Continuous fast charging: always charge as quickly as possible when the vehicle is charging.
- Desired amount of energy in kWh: here you enter the desired amount of energy to be charged within the defined time.
- Planned departure time: specifies the time by which the specified amount of energy should be
- 5 Click on "Transfer" to send the values to your Energy Manager, where they will be implemented.

Further applications

The implementation of the following applications is carried out exclusively on a project-specific basis:

- Off-grid
- Micro-grid
- Semi-off-grid operation
- Power quality

Our TESVOLT Service Line +49 (0) 3491 8797-200 will be happy to plan and configure your system together with you according to your requirements.

10 SYSTEM MONITORING IN MYTESWORLD

10.1 myTESWORLD USER INTERFACE


The myTESWORLD portal is operated from a graphic user interface and displayed in a browser. Current and past data are visualised in the portal. In addition to this, settings can also be adjusted on compatible devices on the connected systems.

Customer view



3 Show/hide the menu	Show or hide the menu
b Role	Shows the role of the current user
C Analysis	Access to forecast data, current data and past data
d Reports	Access to past data incl. download as Excel/PDF
Settings	Configuration of: electric car/charging infrastructure (optional), presentation of PV yield, device names
f Administration	User rights settings and automatic report setup
G Go to	Go to the system displayed or switch roles
Menu display	Reduced menu display with symbols or full display including text
i Bright/dark display	Switch between bright or dark user interface
User settings	User settings and logout of current users

Technician view



3 Show/hide the menu	Show or hide the menu
h Role	Shows the role of the current user
C Monitoring	Access to current and past data incl. download as Excel/PDF
d Go to	Go to the system displayed, switch role or go to the administration section
Menu display	Reduced menu display with symbols or full display including text
f Bright/dark display	Switch between bright or dark user interface
g User settings	User settings and logout of current users

10.2 USER MANAGEMENT

User roles

In the myTESWORLD portal, you have two possible user roles available. The "Customer" role enables the user to view the current system status and various visualisations of power and energy values, and to manage user permissions if necessary. If you want to make changes to settings in the myTESWORLD portal, you need the technician role for this. To assign a technician role to a newly created user, you need another user account with administrator permissions, or you can contact TESVOLT Service Line +49 (0) 3491 8797-200 to have the new account assigned the relevant permissions.

Administrator rights

Rights for the administration of the system can be assigned to the customer and technician roles. In the customer role, settings can only be managed for the rights of other users. Administrator rights can be transferred in two ways. First, administrator rights can be assigned to a user when creating a new EMS, but these rights only apply to this EMS. However, administrator rights can also be granted to entire groups or sub-groups. Administrator group rights can only be set up via the TESVOLT Service Line +49 (0) 3491 87 97 - 200.


New registration in myTESWORLD via the TESVOLT Partner Portal

2


NOTE: Please only create one account per installer/customer via the partner portal. To register other necessary accounts, for example for employees of your company, please use the "Sign up" link on the https://mytesworld.tesvolt.com/page.



Access https://tesvolt.com/ in an internet browser. Click on the "Login Partner Portal" link 📵 in the top right hand corner. If you (as an end customer) already have an account in the myTESWORLD portal, you can move straight on to the next section.




On the login page that opens, click on the "here" link 1.




Now fill in the user registration form and, if you can agree to the information provided, tick the privacy and terms of use b boxes. Finally, click on "Create" 🕻 .

- You will first receive a confirmation email and then a verification email. Click on the "Verification" link in the email. Create and confirm a password in the dialogue box.
- [5] You can now log in to the TESVOLT Partner Portal. To log in to the myTESWORLD portal, open the dashboard page in the partner portal and click on the "myTESWORLD" tile. If you are already on the login page of the myTESWORLD portal, please use the "Log in with Tesvolt" button to log in via the partner portal.

Register a new user directly in the myTESWORLD portal



Access https://mytesworld.tesvolt.com/ in an internet browser. If you are not yet set up as a user in the portal, click on the link "Sign up" 📵. If you already have an account in myTESWORLD, you can move straight on to the next section.



Enter the email address of the new user in the field "E-Mail" (a). The password must be entered in the next two fields 1. After agreeing to the terms of use and confirming the reCaptcha, click on the "Sign up" button (1). You will then receive an email with a link to confirm your registration. Click on this link and log in again if needed.

- NOTE: It is only possible to configure the TESVOLT Energy Manager in myTESWORLD in the technician role. If you do not have a technician account or access to a user account with administrator permissions, please contact the TESVOLT Service Line +49 (0) 3491 87 97 - 200 to activate the role for the desired user(s).
- NOTE: If you have access to a user account with administrator permissions and would like to activate the role for the desired new user(s), follow the procedure described in the section "10.4 Technician role" on page 133.

Groups

Groups combine any number of energy management systems (EMS) for user management. Within a group, global rights can be granted to users, i.e. the rights granted to a user via the group apply to all EMSs in that group. For example, if a new EMS group is added, all users in the group will automatically have access to the EMS according to their group rights, without the user having to register in the EMS. This makes it easier to manage users and rights. For example, if a new technician is hired in a company, a user does not need to be added to each individual EMS, but only once to the group.

The "Group" functionality is therefore recommended for all installation companies with several employees who regularly purchase and install TESVOLT Energy Managers.


Administrator rights can be delegated to qualified users within a group, allowing them to create new EMSs, add users to the EMS, delete users and edit user rights.

NOTE: If you want to set up one or more user subgroups for your company in myTESWORLD, please contact the TESVOLT Service Line +49 (0) 3491 8797-200.


10.3 EMS CONFIGURATION

Setting up the EMS and linking it with the hardware


NOTE: To link an existing EMS to a TESVOLT Energy Manager, you will need a technician clearance, which you will receive after successfully completing the certification training.. For questions about setting up the myTESWORLD portal, please contact the TESVOLT Service Line +49 (0) 3491 8797-200.




Log into myTESWORLD and in the side menu select the "Technician" role 1



Go to the administration section by clicking on the corresponding item 1 in the side menu.



Click the button "Create new EMS" 1 or the menu item "+ Set up a new EMS" 1 in the side menu.



The page "Initialising new EMS" opens. Complete the following fields:

Name (required) > Name freely selectable

Owner (optional) > Email address of the owner


Description (optional) > Information about the EMS

Latitude (optional) > Coordinates of the EMS (geographical latitude)


Longitude (optional) > Coordinates of the EMS (geographical longitude)

Time-zone (optional) > Time zone that the EMS is located in


Finally, confirm your entries by clicking on the "Save" button 1.




Now click on the button "Claim Energy Manager" 1.



Enter the serial number of the TESVOLT Energy Manager (hardware) to be linked in the "Serial number of Energy Manager" field (a) of the new dialogue window. The serial number is found on the stickers included in the packaging of the unit. The serial number begins with "TEM", followed by a 10-digit number. Then select the EMS to be linked from the drop-down menu "Energy management system (EMS)" b. Then click on the "Confirm" button 🕻




When the EMS has been successfully linked, the page will refresh automatically and you can see a confirmation a of the procedure at the top of the page.



Switch back to the administrator role.

Now click on the "Claim EMS" button in the overview 1.



Re-enter the serial number of the TESVOLT Energy Manager (hardware) to be linked in the "Serial number of Energy Manager" a field of the new dialogue window. Select your organisation from the drop-down menu "Add organization objective" (b) (this was created during certification training). Finally, click on the "Claim" button (c).

Editing the EMS




NOTE: To edit an EMS, you need technician clearance.


Log into the myTESWORLD portal, select the "Technician" role and go to the "Administration" section (see steps (1) and (2) in the section "Setting up the EMS and linking it with the hardware" on page 123).



Now click on the button "List EMSs" 1 or "List registered EMSs" 1 in the side menu.



Find the entry of the EMS/TESVOLT Energy Manager and click on the "Edit" button 1




Make the desired changes and then click on the "Save" button 1.

Unlinking an EMS from hardware



NOTE: To unlink an EMS from a TESVOLT Energy Manager, you need technician clearance.

Log into the myTESWORLD portal, select the "Technician" role, go to the "Administration" section and click on "List registered EMSs" in the side menu or on the button "List EMSs". Then, in the entry for the relevant EMS, click on "Edit" (see steps $\begin{bmatrix} 1 \end{bmatrix}$ to $\begin{bmatrix} 3 \end{bmatrix}$ in the section "Editing the EMS" on page 127 et seq.).



Now click on the button "Unlink Energy Manager" 1.

The page will then automatically refresh and in the "Energy Manager" side section there will only be a "Link" button alongside the text "There is currently no Energy Manager linked with this EMS."

Adding users to an EMS




NOTE: To add a user to an EMS, you need administrator permissions.




NOTE: A user who has registered via the TESVOLT Partner Portal must have logged into the myTESWORLD portal once before the user in question is visible in the portal's user management.


Log into the myTESWORLD portal, select the "Technician" role, go to the "Administration" section and click on "List registered EMSs" in the side menu or on the button "List EMSs" (see steps 1 to 2 in the section "Editing the EMS" on page 127 et seq.). Alternatively, you can also make the changes in the customer role. For this, see the section "Administration - notifications" on page 147.



You will now see a list of all the EMSs you have access to. In the entry of the relevant EMS, click on the button "Users" 1



Now click on the button "+ Add User" 1.




Enter the email address of the user in the field "User Email" (a) and then click on "Submit" (b). The user must have previously registered on myTESWORLD with this email address.

- 4 You now return to the "User Administration" page. The new user will be visible in the table. However, newly added users have no permissions assigned to them. Assigning permissions to users is explained in the following section.
- NOTE: If you are an installer, please make sure that you remove the demo rights of customer users at the latest after commissioning, otherwise these users will be unable to access the actual installation

Editing the rights of users of an EMS


NOTE: To edit user permissions for an EMS, you need administrator permissions.

Log into the myTESWORLD portal, select the "Technician" role, go to the "Administration" section and click on "List registered EMSs" in the side menu or on the button "List EMSs"". Then, in the entry of the relevant EMS, click on the button "Users" (see steps $\begin{pmatrix} 1 \end{pmatrix}$ to $\begin{pmatrix} 2 \end{pmatrix}$ in the section "10.4 Technician role" on page 133). Alternatively, you can also make the changes in the customer role. For this, see the section "Administration - notifications" on page 147.




Now click on the button "Change User permissions" (1).





You can now adjust the permissions for the two available roles of the user. If you would like to assign a particular permission to the user, click on the corresponding tick box (see example 1). Usually, the "Customer" role is only assigned read permissions, while the "Technician" role is granted all available permissions. When you have made all the desired changes, click on "Submit" 1





A confirmation page is now displayed, which again shows all the user's rights. If you are happy with the details, click on "Submit" 1.


Deleting users of an EMS




NOTE: To edit user permissions for an EMS, you need administrator permissions.




Log into the myTESWORLD portal, select the "Technician" role, go to the "Administration" section and click on "List registered EMSs" in the side menu or on the button "List EMSs". Then, in the entry for the relevant EMS, click on "Users" (see steps $\begin{bmatrix} 1 \end{bmatrix}$ to $\begin{bmatrix} 2 \end{bmatrix}$ in the section "10.4 Technician role" on page 133 et seq.). Alternatively, you can also make the changes in the customer role. For this, see the section "Administration - notifications" on page 147.



Now click on the button "X Remove User" 1.



Click on the entry field and select the user to be deleted by clicking on the tick box b.




You now need to click once more outside the expanded drop-down menu in order to collapse it. Finally, click on "Submit" 1.


10.4 TECHNICIAN ROLE

Log into the myTESWORLD portal, select the "Technician" role and go to the "Monitoring" section.

About EMS




You can now see an overview of all EMSs that the user currently logged in has access to. Select the desired entry by clicking on it 1.




You now come to the overview page for the selected "EMS: Technician" \rightarrow "Monitoring" \rightarrow "About EMS".

EMS Measurements



In the side menu, click on "Technician" → "Monitoring" → "EMS Measurements". In the window that opens, you can see various sections of grouped measurements. The first section, "Meters & Sensors" a encompasses the sensors of all logical devices. To open a section, click on it.




At the top of the page, directly below the title "Measurement-Analysis" (a) you can define the period and start date of the measurements displayed. To apply the filter, click on "Select" (b). In the opened section, you can see graphs of the measurements in the centre. If you would like more specific information, you can click on any point in the diagram (c). This will open a small window (d) showing the numerical values of all measurements displayed in the diagram for the selected point in time. By clicking on an item in the legend of the diagram (e), you can hide individual series of measurements. You can also change more settings by clicking on "Measurement-series selection" (f) (see next step).

0

NOTE: Delay between measurement and display

Please note that there may be a delay of 45 minutes between the actual measurement and the display of the measurement data in the portal. This delay only occurs when selecting a view that is more than 24 hours old. If you select the current day or the last 24 hours in the view, the display is in near real time.






If you open the section "Measurement-series selection", under "Devices" 1 you can see all the sensors whose measurements are displayed in the diagram. Under "Measurands" (1) you can see the measurands currently being measured and displayed. If you would like to remove sensors or restore previously removed sensors, click on the tick (). This will open a pop-up window when you can activate or deactivate sensors by clicking on them. If you would like change the selection of measurands, click on the tick (1). To apply the changes to devices (sensors) or measurands, click on "Display" (2).


Energy Manager Condition






At the top of the section, directly below the section heading "Course" (a) you can define the period and start date of the measurements displayed. To apply the filter, click on "Select" 1. In the opened section, you can see graphs of the measurements in the centre. If you would like more specific information, you can click on any point in the diagram. This will open a small window showing the numerical values of all measurements displayed in the diagram for the selected point in time. By clicking on an item in the legend of the diagram, you can hide individual series of measurements. By clicking on "Measurement-series selection" 🕻, you can select or deselect the available measurands.

Energy Manager Heartbeats



At the top of the section "Heartbeat Details", directly below the section heading, you can set the period f i and the EMS status f i to filter the data displayed in the table. To apply the filter, click on "Filter" f c .


Energy Manager Logs



At the top of the section "Listing of all log events", directly below the section heading, you can create a filter for displaying the log events: time period selection 📵, device selection 🕦 content of the message $oldsymbol{c}$. Confirm the filter settings by clicking on "Filter" $oldsymbol{d}$. If you are only looking for errors, you can click to deactivate (1). This makes the list clearer, as all "OK" messages will be hidden. Alternatively/ additionally, you can also search for specific terms in the messages using the $oldsymbol{0}$ box.

bat.TesvoltPCS_Tesvolt_59905.0 DC Voltage bat.TesvoltPCS_Tesvolt_59905.0 SoH

Energy Manager Sensors



At the top of the page you will find the "Devices" section. All physical devices are listed here, along with the sensors assigned to them. Use the filter 📵 to search for a specific device/meter. To see the individual sensors, click on the "Sensors" field (1), which will then be expanded. In the following section, "Meters", you will find all logical devices described as meters. To see the physical devices assigned to them, click on the corresponding "Devices" field (). For information on the corresponding sensors, click on the "Sensors" field d

10.5 CUSTOMER VIEW

Log into the myTESWORLD portal and select the "Customer" role. A list of all EMSs assigned to the user will be displayed. Select the desired EMS by clicking on it.

Current Status



In the section "Energy-flow" 1 you can see a schematic diagram of the physical devices in the system, including current energy flow. "Consumption", in the middle of the circle, is always the physical device "User 1". In the section "Self-sufficiency" 🕕 (on the right), you can see what percentage of the system's own demand is currently covered by its own electricity production. To see the numerical values, move the mouse pointer over the graphic (mouse-over). In the section "Feed-in" 🚺 you can see how much electricity is being fed into the utility grid.

Summarising the energy flow



If there are several physical devices of the same type, the system overview on the "Energy-flow" page can become hard to read. In this case, you can select a grouped display of the energy flow 1 by clicking as shown.



In the grouped display, all devices of the same type are represented in the overview by just one symbol. Click on "E-Board" (a) to switch back to the ungrouped view.

Analysis - Energy-Balance

Consumption





At the top of the page "Energy-Balance" \rightarrow "Consumption", you can filter the period and start date $\stackrel{\circ}{=}$ of the data displayed in the diagram. To apply the filter, click on "Select" 1. By clicking on the menu symbol 🕻 you can access options to print the diagram, export it as a graphic, or download it as a document (xls, csv). Click on an entry in the legend \bigcirc to hide or show the corresponding values in the diagram. For the other diagrams of the energy balance, click on one of the other menu options 😉


Generation

 \bigcap



At the top of the page "Energy-Balance" \rightarrow "Generation", you can filter the period and start date ${}^{\circ}$ of the data displayed in the diagram. To apply the filter, click on "Select" 1. By clicking on the menu symbol 🕠 you can access options to print the diagram, export it as a graphic, or download it as a document (xls, csv). Click on an entry in the legend \bigcirc to hide or show the corresponding values in the diagram. For the other diagrams of the energy balance, click on one of the other menu options (2).

Energy Balance



At the top of the page "Energy-Balance" ightarrow "Energy Balance", you can filter the period and start date a of the data displayed in the diagram. To apply the filter, click on "Select" b. By clicking on the arrow symbol ${\color{orange} ilde{ to}}$ you can flip the diagram horizontally. Click on the drop-down menu ${\color{orange} ilde{ to}}$ to select which values (generation/consumption) should be displayed. The numerical values are displayed if you move the mouse pointer over the relevant areas of the diagram (mouse-over). For the other diagrams of the energy balance, click on one of the other menu options (2).

Indexes

1 0 8 TESWORLD Power Consumption & Generation Plant name Current Status 09/01/2022 11:50 AM 000 Energy-Balance Ser Ser PV Yield SETTINGS Feed-in (Gi 1.1 % Grid-de 0.9 % (i) User Perm

At the top of the page "Energy-Balance" \rightarrow "Indexes", you can filter the period and start date \bigcirc of the data displayed in the diagram. To apply the filter, click on "Select" **b**. Click on an entry in the legend 🕡 to hide or show the corresponding values in the diagram. The numerical values are displayed if you move the mouse pointer over the relevant areas of the diagram (mouse-over). For the other diagrams of the energy balance, click on one of the other menu options \mathbf{d} .

Analysis - Measurement-Analysis

Power






At the top of the page "Measurement-Analysis" \rightarrow "Power", you can filter the period and start date $_{1}$ of the data displayed in the diagram. To apply the filter, click on "Select" 1. By clicking on the switch labelled "Stack", you can switch between display as a stacked chart or as a line graph. In the stacked chart display, the positive values show the generation and the negative the consumption. By clicking on the menu symbol \bigcirc you can access options to print the diagram, export it as a graphic, or download it as a document (xls, csv). Click on an entry in the legend 😉 to hide or show the corresponding values in the diagram. Click on "Breakdown of Consumption" 🚺 or "Breakdown of Generation" 😲 to show a corresponding diagram in each case. The numerical values are displayed if you move the mouse pointer over the relevant areas of the diagram (mouse-over). For the "Battery" diagram, click on the menu option (h).

Battery






At the top of the page "Measurement-Analysis" ightarrow "Battery", you can filter the period and start date ${ ilde a}$ of the data displayed in the diagram. To apply the filter, click on "Select" 1. By clicking on "Measurement-series selection" (c), you can select or deselect the measurands available to display. By clicking on the menu symbol $\stackrel{1}{\bullet}$ you can access options to print the diagram, export it as a graphic, or download it as a document (xls, csv). Click on an entry in the legend 🙂 to hide or show the corresponding values in the diagram. The numerical values are displayed if you move the mouse pointer over the relevant areas of the diagram (mouse-over). For the "Power" diagram, click on the relevant menu option


Reports - Sensor Report





At the top of the page you will find the "Devices" section. All physical devices are listed here, along with the sensors and measurands assigned to them. Use the filter 🔞 to search for a specific device. For information on the corresponding sensors or the available measurands, click on the "Sensors" field $oldsymbol{\mathfrak{h}}$. To open the next section, "Meters", click on the field 🚺 In this section you will find all logical devices described as meters, as well as the physical devices they measure and the available measurands. To open the last section, "Download", click on the field 📵 In this section you can download any sensor data.






In the "Devices" section, select a physical device, e.g. the grid meter 1. In the corresponding "Sensors" section b, you can see that the meter measures the amount drawn from the grid and the grid feed-in. Open the "Meters" section by clicking on it, and look for the corresponding logical device c. The first two device names begin with "bat" (battery) and "inv" (inverter), so they cannot be the grid meter. Click on the "Devices" field of the third meter to check whether this is the "Grid" meter. As it is measuring all existing physical devices, this must be the "Grid" meter. Now click on the corresponding "Sensors" field to see the available measurands 😉 If you would like to download the measurements, open the "Download" section by clicking on it.

Select the desired time period 1 incl. date and time zone. Enter the temporal resolution required 😲 In the "Select data type" field (1) you can choose between power and energy, or whether you want interpolated data (missing data is calculated), average values or original meter data. When you have made a selection, another field appears where you can select the sensors and measurands. Finally, specify separators and decimals (i). If you want to check the data before the final export, click on "Preview" (i), or click on "Download" (k) to download the data straight away.


1

[2]

Reports - PV Yield and Settings - PV Yield




Open "Settings" \rightarrow "PV Yield" \bigcirc for the configuration of "Reports" \rightarrow "PV Yield". At the bottom of the page, an additional section, "Settings", is shown. If applicable select the PV installation 🕦 whose settings you want to configure. Enter the predicted yields of the PV installation 🕻 and the installation size d and then click on "Submit" b



At the top of the page "Reports" \rightarrow "PV Yield", you can switch the display between the different PV installations if applicable (a). By clicking on the menu symbol (b) you can access options to print the diagram, export it as a graphic, or download it as a document (xls, csv). Click on an entry in the legend to hide or show the corresponding values in the diagram. The table allows you to see the values as either "kWh" or "kWh/kWp", and you can switch between these displays using the buttons $\mathbf{0}$ (please note that for this the installation size must have been entered in "Settings" -> "PV Yield").


© TESVOLT AG Subject to technical changes! RD_TI_093_E_251117_en-EN Revision: I.01 11/2025

Reports - Energy Report



At the top of the page you can select the year 📵 whose data you want to display. By clicking on the menu symbol 🕦 you can access options to print the diagram, export it as a graphic, or download it as a document (xls, csv). Click on an entry in the legend 🕠 to hide or show the corresponding values in the diagram. Using the two buttons \bigcirc below the table, you can export the data in the table as a PDF or XLS file.

Reports - Meter Report




At the top of the page you can define the terms for a specific meter report. Enter the desired date and time in the field (a), select the relevant meter (b) and click on "Select" (c) to display the meter report. At the top of the section "Monthly Meter Readings", you can select the year 🕕 whose data you want to display in the table below. Clicking on "Interpolated Values" 🕑 will take you to the page "Reports" 🗲 "Sensor Report", where you can download interpolated data, among other things (see the section "Reports - Sensor Report" on page 142, step (2).

Settings - PV Yield


1 In this section you can configure the settings for the section "Reports" > "PV Yield". Detailed information can be found in the section "Reports - Sensor Report" on page 142, step 2

Settings - Devices



Here you can change the names of physical devices. If necessary, use the search field 1 to find the device. To edit a name, click on the cog symbol next to the device entry 🕩







Enter a new name in the field 1 . To reset the name to the original, automatically assigned name, click on "Delete" **b**. To apply the changes, click on "Submit" **c**.

Administration - notifications






The TESVOLT Energy Manager can automatically send notifications to any users when devices generate messages or sensors detect measurement values inside or outside certain value ranges. To set up notifications, click on notifications 3 in the side menu and then on "Create new reporter" 1.




Enter a descriptive name in the "Reporter name" field ①. A time period must be specified in the "Probing window" ⓑ within which the conditions specified below must be met in order to create and send a report. If you tick the "Notify on no longer triggered" box ⑥, a notification will be sent as soon as the conditions are no longer met. The "Fulfill for" field ⑥ determines whether a notification is sent when "all" conditions are met or when "one" of the conditions is met. In the "Select user" box ②, you must now select the recipient(s) of the notifications (only registered users can be selected). As soon as a user is selected, a table with the email address appears on the right side. After the entry, you can use two tick boxes to select whether a notification is sent via email ⑥ and/or push notifications ③. Below the table there are two buttons: "Log Event Reporter" ⑥ and "Sensor Reporter" ⑥. Here, you can select the data to be evaluated for notifications. Clicking on "Log Event Reporter" evaluates the log messages from the device, and clicking on "Sensor Reporter" evaluates the actual measurement values. Click on desired button.



Clicking on "Log Event Reporter" will display other fields. In the "To be met for devices" box 1, specify whether a notification is to be sent if all messages from a device meet the conditions, or if only one message meets the conditions. If you tick the "Send message on not OK" box 1, all messages from the selected device that are not OK messages will be sent as a notification. If it is not ticked, all messages are sent that contain the text entered in box 1. If you tick the "Probe all devices" box 1, messages from all devices will be checked. If the box is not ticked, you can select a specific device using the "Select device" 1 or "Insert device" 1 boxes. Finally, click on "Submit" 1.






Clicking on "Sensor Reporter" will display other fields. In the "Measurement Kind" box (a), you can select whether the value is an average value, energy value or power value. In the "Sensor" drop-down menu by you can select the desired sensor. The "Time Resolution" box clallows you to determine the temporal resolution of the measurements. The "Condition for Trigger" box 🚺 allows you to define how the "Threshold" 📵 is interpreted (the "Threshold" is always positive, depending on the selection for "Measurement Kind" W/Wh/V/A/°C/%). Then, click on "Submit" 1.

Administration - User permissions





If you would like to set up a new user, click on "+ Add User" (a). To change the permissions of existing users, click on "Change User permissions" 🕕. On the page that opens, you can then add or remove permissions by clicking on them. Finally, click on "Confirm". You must then confirm the changed permissions again on a new page.

To delete a user, click on "X Remove User" (c). On the page that opens, select the user to be removed and click on "Confirm".

User permissions can also be managed from the technician role (see also the section "7.8 User management" on page 29).

11 DECOMMISSIONING



WARNING: Not following the decommissioning procedures for the system components can lead to damage to the units.

Before decommissioning the system, take careful note of the decommissioning procedures for the individual system components in the relevant product documentation, as not following the prescribed decommissioning processes can lead to damage to the units.


1 To decommission the Energy Manager, disconnect it from the power supply and ensure it is voltage-free.

12 FIRMWARE-UPDATE

NOTE: With version 3.0.0 and higher, users can update the firmware themselves. If you are running a version prior to 3.0.0, please contact TESVOLT Support.

Proceed as follows to update the firmware:

In the side menu, click on System Settings > FW Upgrade.




You will see the status of the FW version 📵 used by your TESVOLT Energy Manager, as well as log entries from past FW updates **b**.


- [3] If there is a newer firmware version available, start the update by clicking on "Upgrade". The new firmware version is then installed, followed by an automated restart. Notifications indicate the progress.
- As soon as the TESVOLT Energy Manager is restarted, check whether your EMS appears to be working. As soon as you have ensured fault-free operation, complete the update by clicking on "Finalise". The TESVOLT Energy Manager will then install the update a second time. After the TESVOLT Energy Manager is restarted for the second time, you have successfully completed the process.

13 ANALYSIS FUNCTION AND TROUBLESHOOTING

13.1 NETWORK ANALYSIS




13.2 INPUTS AND OUTPUTS ANALYSIS



14 EXAMPLE ENERGY SERVICE STRATEGIES (MULTI-USE)


14.1 PEAK SHAVING + SELF-CONSUMPTION OPTIMISATION



In this energy service strategy, the energy service strategies peak shaving and self-consumption optimisation are combined to achieve the benefits listed below.

For this multi-use application, only the Basic version of the TESVOLT Energy Manager is required.

Configuring this energy service strategy in the decision tree



Benefits

- Maintains a minimum usable energy content to guarantee peak shaving
- With the Pro version and dynamic peak shaving, a maximum battery lifespan can be guaranteed.


14.2 FORECAST-BASED CHARGING + SELF-CONSUMPTION OPTIMISATION



In this energy service strategy, the energy service strategies forecast-based charging and self-consumption optimisation are combined to achieve the benefits listed below.

For this multi-use application, the Pro version of the TESVOLT Energy Manager is required.


Configuring this energy service strategy in the decision tree



Benefits

- Extends the battery lifespan (lithium-ion batteries age more quickly in the 80–100% SoC range)
- Battery is used effectively during its lifespan
- Guarantees maximum degree of system self-sufficiency


Forecast-based charging + peak shaving + self-consumption optimisation



In this energy service strategy, the energy service strategies forecast-based charging, peak shaving and self-consumption optimisation are combined to achieve the benefits listed below.

For this multi-use application, the Pro version of the TESVOLT Energy Manager is required.

Configuring this energy service strategy in the decision tree



Benefits:

- Extends the battery lifespan (lithium-ion batteries age more quickly in the 80-100% SoC range)
- Maintains a minimum usable energy content to guarantee peak shaving even where forecast data differs (e.g. weather report)
- Battery is used effectively during its lifespan

15 MAINTENANCE

Check all screwed electrical connections: Loose connections must be retightened.

Use a dry cleaning cloth to clean the unit. The connections must be kept free of moisture. Do not use solvents of any kind!

16 DISPOSAL

Once a unit has been withdrawn from service, it must be disposed of in accordance with the locally applicable disposal regulations for electronic waste.

17 LEGAL NOTICE

TESVOLT Energy Manager Installation and Operating Manual

Last revised: 11/2025

Applies to Tesvolt Energy Manager version 3.20 or higher

Subject to technical changes.

TESVOLT AG

Am Heideberg 31 06886 Lutherstadt Wittenberg Germany

TESVOLT Service Line +49 (0) 3491 8797-200

service@tesvolt.com

www.tesvolt.com

Legal notice on use of the contents

The information contained in these documents is the property of TESVOLT AG. It may not be published in whole or in part without written permission from TESVOLT AG.

www.tesvolt.com